



DIGITAL KEYBOARD

PSR-I400

Data List

Contents

Voice List	2
Drum Kit List.....	9
Style List	16
Riyaz List	17
Song List.....	18
Arpeggio List	19
Music Database List.....	20
Effect Type List.....	22
Harmony Types.....	22
Reverb Types.....	22
Chorus Types.....	22

Voice List

Maximum Polyphony

The instrument has 48-note maximum polyphony. This means that it can play a maximum of up to 48 notes at once, regardless of what functions are used. Auto accompaniment uses a number of the available notes, so when auto accompaniment is used the total number of available notes for playing on the keyboard is correspondingly reduced. The same applies to the Split Voice and Song functions. If the maximum polyphony is exceeded, earlier played notes will be cut off and the most recent notes have priority (last note priority).

NOTE

- The Voice List includes MIDI program change numbers for each voice. Use these program change numbers when playing the instrument via MIDI from an external device.
- Program change numbers are often specified as numbers "0-127". Since this list uses a "1-128" numbering system, in such cases it is necessary to subtract 1 from the transmitted program change numbers to select the appropriate sound: e.g. to select No. 2 in the list, transmit program change number 1.

Panel Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
INDIAN				
1	0	113	21	Harmonium Single
2	0	114	21	Harmonium Double
3	0	115	21	Harmonium Triple
4	0	123	112	Shehnai
5	0	123	111	Sarangi 1
6	0	124	111	Sarangi 2
7	0	124	112	Pungi
8	0	117	74	Bansuri
9	0	112	105	Sitar 1
10	0	113	105	Sitar 2
11	0	115	105	Sarod
12	0	97	16	Santoor
13	0	114	105	Tanpura
14	0	120	108	Indian Banjo
15	0	124	26	Mandolin
16	0	121	108	Swarmandal
17	0	117	105	Ektara
18	0	118	105	East Rabab
19	0	0	10	Bell 1
20	0	0	99	Bell 2
21	0	0	89	Early Morning
22	0	20	96	Waves
23	0	117	12	Sun Vibes
24	0	116	117	Tabla
25	126	0	116	Tabla Kit 1
26	126	0	117	Tabla Kit 2
27	126	0	40	Indian Kit 1
28	126	0	115	Indian Kit 2
29	126	0	33	Indian Mix Kit
30	126	0	112	Animal Kit
PIANO				
31	0	112	1	Grand Piano
* 32	-	-	-	Octave Piano
33	0	112	2	Bright Piano
34	0	112	7	Harpsichord
* 35	-	-	-	Octave Harpsichord
36	0	112	4	Honky Tonk Piano
37	0	112	3	MIDI Grand Piano
38	0	113	3	CP80
* 39	-	-	-	Piano & Strings
* 40	-	-	-	Piano Pad
E.PIANO				
41	0	114	5	Cool! Galaxy Electric Piano
42	0	113	6	Hyper Tines
* 43	-	-	-	Tiny Electric Piano
44	0	112	5	Funky Electric Piano
45	0	112	6	DX Modern Electric Piano
46	0	114	6	Venus Electric Piano
* 47	-	-	-	Electric Piano Pad

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
48	0	112	8	Clavi
ORGAN				
49	0	118	19	Cool! Organ
50	0	117	19	Cool! Rotor Organ
51	0	112	17	Jazz Organ 1
52	0	113	17	Jazz Organ 2
53	0	112	19	Rock Organ
54	0	114	19	Purple Organ
55	0	112	18	Click Organ
56	0	116	17	Bright Organ
57	0	127	19	Theater Organ
58	0	121	20	16'+2' Organ
59	0	120	20	16'+4' Organ
* 60	-	-	-	Full Organ
61	0	113	20	Chapel Organ
62	0	112	20	Pipe Organ
63	0	112	21	Reed Organ
ACCORDION				
64	0	112	22	Musette Accordion
65	0	113	22	Traditional Accordion
66	0	113	24	Bandoneon
67	0	113	23	Modern Harp
68	0	112	23	Harmonica
GUITAR				
69	0	116	25	Dynamic Nylon Guitar
70	0	118	30	Dynamic Overdriven
71	0	112	25	Classical Guitar
72	0	112	26	Folk Guitar
73	0	112	27	Jazz Guitar
* 74	-	-	-	Octave Jazz Guitar
75	0	117	28	60s Clean Guitar
76	0	113	26	12Strings Guitar
77	0	112	28	Clean Guitar
78	0	113	27	Octave Guitar
79	0	112	29	Muted Guitar
80	0	112	30	Overdriven Guitar
81	0	112	31	Distortion Guitar
BASS				
82	0	116	34	Dynamic Electric Bass
83	0	112	34	Finger Bass
84	0	112	33	Acoustic Bass
85	0	112	35	Pick Bass
86	0	112	36	Fretless Bass
87	0	112	37	Slap Bass
88	0	118	40	DX100 Bass
89	0	119	40	Ramp Bass
90	0	120	40	Dark Core Bass
91	0	119	39	Fat Lo Bass
92	0	122	40	Bleep Bass
93	0	121	40	Funk Bass
94	0	112	39	Synth Bass

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
95	0	113	39	Hi-Q Bass
96	0	113	40	Dance Bass
STRINGS				
97	0	112	49	Strings
98	0	112	50	Chamber Strings
99	0	115	50	Marcato Strings
100	0	113	50	Slow Strings
* 101	-	-	-	Octave Strings
* 102	-	-	-	Orchestra Section
103	0	112	45	Tremolo Strings
104	0	112	51	Synth Strings
105	0	112	46	Pizzicato Strings
* 106	-	-	-	Octave Pizzicato Strings
107	0	112	41	Violin
108	0	112	43	Cello
* 109	-	-	-	Strings Session
110	0	112	44	Contrabass
111	0	112	47	Harp
* 112	-	-	-	Octave Harp
113	0	112	106	Banjo
114	0	112	56	Orchestra Hit
* 115	-	-	-	Orchestra Hit & Timpani
116	0	96	105	Tambra
117	0	96	106	Rabab
118	0	98	106	Oud
119	0	0	107	Shamisen
120	0	97	106	Gopichant
121	0	0	108	Koto
122	0	96	108	Taisho-kin
123	0	0	16	Dulcimer 1
124	0	97	108	Kanoon
125	0	96	16	Cimbalom
**126	-	-	-	Tremolo Cimbalom
127	0	40	47	Yang Qin
**128	-	-	-	Tremolo Yang Qin
CHOIR				
129	0	112	53	Choir
130	0	113	53	Vocal Ensemble
131	0	112	55	Air Choir
* 132	-	-	-	Octave Choir
133	0	112	54	Vox Humana
SAXOPHONE				
134	0	117	67	Sweet! Tenor Sax
135	0	113	65	Sweet! Soprano Sax
136	0	116	66	Sax Section
* 137	-	-	-	Ballroom Sax Ensemble
* 138	-	-	-	Sax & Trombone
139	0	112	67	Tenor Sax
140	0	112	66	Alto Sax
141	0	112	65	Soprano Sax
142	0	112	68	Baritone Sax
143	0	114	67	Breathy Tenor Sax
144	0	112	72	Clarinet
145	0	112	69	Oboe
146	0	112	70	English Horn
147	0	112	71	Bassoon
148	0	116	72	WoodWind Section
149	0	97	112	Hichiriki
TRUMPET				
150	0	115	57	Sweet! Trumpet
151	0	112	57	Trumpet
152	0	112	58	Trombone
153	0	113	58	Trombone Section
154	0	112	60	Muted Trumpet
155	0	112	61	French Horn
* 156	-	-	-	Octave French Horns

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
157	0	112	59	Tuba
BRASS				
158	0	112	62	Brass Section
159	0	113	62	Big Band Brass
160	0	116	62	Octave Brass
* 161	-	-	-	Ballroom Brass
* 162	-	-	-	Jazz Brass Section
* 163	-	-	-	Orchestra Brass
164	0	113	56	Brass Hit
165	0	113	63	80s Brass
* 166	-	-	-	Fat Synth Brass
167	0	119	62	Mellow Horns
168	0	115	63	Funky Brass
169	0	114	63	Techno Brass
170	0	112	63	Synth Brass
FLUTE				
171	0	114	74	Sweet! Flute
172	0	113	76	Sweet! Pan Flute
173	0	112	74	Flute
* 174	-	-	-	Flute & Clarinet
175	0	112	73	Piccolo
176	0	112	76	Pan Flute
177	0	112	75	Recorder
178	0	112	80	Ocarina
SYNTH LEAD				
179	0	104	82	RS Saw Lead 1
180	0	106	82	RS Saw Lead 2
181	0	114	84	RS Dist Lead
182	0	127	81	RS Dual Square
183	0	107	82	RS Ramp Lead
184	0	108	82	RS Tech Saw
185	0	119	85	RS Quack Lead
186	0	109	82	RS Dual Saw
187	0	105	82	RS Sync 1
188	0	119	88	RS Sync 2
189	0	112	81	Square Lead
190	0	112	82	Sawtooth Lead
191	0	112	88	Under Heim
192	0	112	85	Portatone
193	0	115	82	Analogon
194	0	119	82	Fargo
195	0	112	86	Voice Lead
196	0	121	82	Funky Lead
* 197	-	-	-	Octave Lead
* 198	-	-	-	Wah Square Lead
* 199	-	-	-	Resonance Lead
* 200	-	-	-	Quack Lead
* 201	-	-	-	5th Wah Lead
* 202	-	-	-	Super 5th Lead
SYNTH PAD				
* 203	0	116	99	Dynamic Chime
204	0	126	90	RS Analog Pad
205	0	123	90	RS Synth Pad
206	0	113	92	RS Warm Pad
207	0	116	91	RS Short Resonance
208	0	124	90	RS Noise Pad
209	0	125	90	RS Tekno Man
210	0	118	89	Sweet Heaven
211	0	121	89	Dream Heaven
212	0	113	89	Symbiont
213	0	112	99	Stardust
214	0	112	92	Xenon Pad
215	0	112	95	Equinox
216	0	112	89	Fantasia
217	0	113	90	Dark Moon
218	0	112	101	Brightness

Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
219	0	113	101	Bell Pad
PERCUSSION				
220	0	112	12	Vibraphone
221	0	112	13	Marimba
**222	-	-	-	Tremolo Marimba
223	0	112	14	Xylophone
**224	-	-	-	Tremolo Xylophone
225	0	112	115	Steel Drums
**226	-	-	-	Tremolo Steel Drum
227	0	112	9	Celesta
228	0	112	11	Music Box
229	0	112	15	Tubular Bells
230	0	112	48	Timpani
**231	-	-	-	Timpani Roll
DRUM KITS				
232	127	0	88	Power Kit
233	127	0	1	Standard Kit 1
234	127	0	2	Standard Kit 2
235	127	0	9	Room Kit
236	127	0	17	Rock Kit
237	127	0	25	Electronic Kit
238	127	0	59	T8 Kit
239	127	0	60	T9 Kit
240	127	0	26	Analog Kit
241	127	0	113	Dance Kit
242	127	0	33	Jazz Kit
243	127	0	41	Brush Kit
244	127	0	49	Symphony Kit
245	126	0	1	SFX Kit 1
246	126	0	2	SFX Kit 2
247	126	0	21	Bass Drum Kit
248	126	0	22	Reverse Bass Drum Kit
249	126	0	125	China Kit 1
250	127	0	127	China Kit 2
251	126	0	37	Arabic Kit
252	126	0	41	Cuban Kit
ARPEGGIO				
253	-	-	-	Concerto
254	-	-	-	Chambers
255	-	-	-	Pizzicato Strings
256	-	-	-	Latin Rock
257	-	-	-	Brass Section 1
258	-	-	-	Brass Section 2
259	-	-	-	Funk Brass
260	-	-	-	Piano Chord
261	-	-	-	Piano Ballad
262	-	-	-	Piano Arpeggio
263	-	-	-	Hybrid
264	-	-	-	Synth Sequence
265	-	-	-	Guitarist
* 266	-	-	-	Strum
267	-	-	-	Pickin'
268	-	-	-	Spanish
269	-	-	-	Synth Chords
270	-	-	-	Funky Clavi
271	-	-	-	Reggae Organ
272	-	-	-	Harpeggio
273	-	-	-	Analog Sequence
274	-	-	-	Sawtooth
275	-	-	-	Percussion Arpeggio
276	-	-	-	Trill
277	-	-	-	Club Beat
278	-	-	-	R&B Loop
279	-	-	-	Club Adds
280	-	-	-	Samba
281	-	-	-	Indian

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
282	-	-	-	Arabic
283	-	-	-	Finger Bass Left
284	-	-	-	Combo Jazz Left
285	-	-	-	Paul's Bass Left
286	-	-	-	Trance Bass Left
287	-	-	-	Acid Bass Left
288	-	-	-	Piano Ballad Left
289	-	-	-	Salsa Piano Left
290	-	-	-	Piano Arpeggio Left
291	-	-	-	Guitar Arpeggio Left
292	-	-	-	Strum Left
293	-	-	-	Teen Tal C
294	-	-	-	Teen Tal F
295	-	-	-	Teen Tal A
296	-	-	-	Dadra D
297	-	-	-	Dadra E
298	-	-	-	Dadra G

XGlite Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
XG PIANO				
299	0	0	1	Grand Piano
300	0	1	1	Grand Piano KSP
301	0	18	1	Mellow Grand Piano
302	0	40	1	Piano Strings
303	0	41	1	Dream
304	0	0	2	Bright Piano
305	0	1	2	Bright Piano KSP
306	0	0	3	Electric Grand Piano
307	0	1	3	Electric Grand Piano KSP
308	0	32	3	Detuned CP80
309	0	40	3	Layered CP 1
310	0	41	3	Layered CP 2
311	0	0	4	Honky Tonk Piano
312	0	1	4	Honky Tonk Piano KSP
313	0	0	5	Electric Piano 1
314	0	1	5	Electric Piano 1 KSP
315	0	18	5	Mellow Electric Piano
316	0	32	5	Chorus Electric Piano 1
317	0	40	5	Hard Electric Piano
318	0	45	5	Velocity Crossfade Electric Piano 1
319	0	64	5	60s Electric Piano
320	0	0	6	Electric Piano 2
321	0	1	6	Electric Piano 2 KSP
322	0	32	6	Chorus Electric Piano 2
323	0	33	6	DX Electric Piano Hard
324	0	34	6	DX Legend Electric Piano
325	0	40	6	DX Phase Electric Piano
326	0	41	6	DX + Analog Electric Piano
327	0	42	6	DX Koto Electric Piano
328	0	45	6	Velocity Crossfade Electric Piano 2
329	0	0	7	Harpsichord 1
330	0	1	7	Harpsichord KSP
331	0	25	7	Harpsichord 2
332	0	35	7	Harpsichord 3
333	0	0	8	Clavi
334	0	1	8	Clavi KSP
335	0	27	8	Clavi Wah
336	0	64	8	Pulse Clavi
337	0	65	8	Pierce Clavi
XG CHROMATIC				
338	0	0	9	Celesta
339	0	0	10	Glockenspiel
340	0	0	11	Music Box 1
341	0	64	11	Music Box 2
342	0	0	12	Vibraphone
343	0	1	12	Vibraphone KSP
344	0	45	12	Hard Vibraphone
345	0	0	13	Marimba
346	0	1	13	Marimba KSP
347	0	64	13	Sine Marimba
348	0	97	13	Balimba
349	0	98	13	Log Drums
350	0	0	14	Xylophone
351	0	0	15	Tubular Bells
352	0	96	15	Church Bells
353	0	35	16	Dulcimer 2
354	0	97	15	Carillon
XG ORGAN				
355	0	0	17	Drawbar Organ 1
356	0	32	17	Detuned Drawbar Organ
357	0	33	17	60s Drawbar Organ 1
358	0	34	17	60s Drawbar Organ 2
359	0	35	17	70s Drawbar Organ 1

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
360	0	36	17	Drawbar Organ 2
361	0	37	17	60s Drawbar Organ 3
362	0	38	17	Even Bar Organ
363	0	40	17	16+2'2/3 Organ
364	0	64	17	Organ Bass
365	0	65	17	70s Drawbar Organ 2
366	0	66	17	Cheezy Organ
367	0	67	17	Drawbar Organ 3
368	0	0	18	Percussive Organ 1
369	0	24	18	70s Percussive Organ
370	0	32	18	Detuned Percussive Organ
371	0	33	18	Light Organ
372	0	37	18	Percussive Organ 2
373	0	0	19	Rock Organ
374	0	64	19	Rotary Organ
375	0	65	19	Slow Rotary Organ
376	0	66	19	Fast Rotary Organ
377	0	0	20	Church Organ 1
378	0	32	20	Church Organ 3
379	0	35	20	Church Organ 2
380	0	40	20	Notre Dame
381	0	64	20	Organ Flute
382	0	65	20	Tremolo Organ Flute
383	0	0	21	Reed Organ
384	0	40	21	Puff Organ
385	0	0	22	Accordion
386	0	32	22	Accord It
387	0	0	23	Harmonica 1
388	0	32	23	Harmonica 2
389	0	0	24	Tango Accordion 1
390	0	64	24	Tango Accordion 2
XG GUITAR				
391	0	0	25	Nylon Guitar 1
392	0	16	25	Nylon Guitar 2
393	0	25	25	Nylon Guitar 3
394	0	43	25	Velocity Guitar Harmonics
395	0	96	25	Ukulele
396	0	0	26	Steel Guitar 1
397	0	16	26	Steel Guitar 2
398	0	35	26	12-string Guitar
399	0	40	26	Nylon & Steel Guitar
400	0	41	26	Steel Guitar with Body Sound
401	0	96	26	Mandolin
402	0	0	27	Jazz Guitar
403	0	18	27	Mellow Guitar
404	0	32	27	Jazz Amp
405	0	0	28	Clean Guitar
406	0	32	28	Chorus Guitar
407	0	0	29	Muted Guitar
408	0	40	29	Funk Guitar 1
409	0	41	29	Muted Steel Guitar
410	0	43	29	Funk Guitar 2
411	0	45	29	Jazz Man
412	0	0	30	Overdriven Guitar
413	0	43	30	Guitar Pinch
414	0	0	31	Distortion Guitar
415	0	40	31	Feedback Guitar 1
416	0	41	31	Feedback Guitar 2
417	0	0	32	Guitar Harmonics 1
418	0	65	32	Guitar Feedback
419	0	66	32	Guitar Harmonics 2
XG BASS				
420	0	0	33	Acoustic Bass
421	0	40	33	Jazz Rhythm
422	0	45	33	Velocity Crossfade Upright Bass

Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
423	0	0	34	Finger Bass 1
424	0	18	34	Finger Bass Dark
425	0	27	34	Flange Bass
426	0	40	34	Bass & Distorted Electric Guitar
427	0	43	34	Finger Slap Bass
428	0	45	34	Finger Bass 2
429	0	65	34	Modulated Bass
430	0	0	35	Pick Bass
431	0	28	35	Muted Pick Bass
432	0	0	36	Fretless Bass 1
433	0	32	36	Fretless Bass 2
434	0	33	36	Fretless Bass 3
435	0	34	36	Fretless Bass 4
436	0	96	36	Synth Fretless
437	0	97	36	Smooth Fretless
438	0	0	37	Slap Bass 1
439	0	27	37	Resonant Slap
440	0	32	37	Punch Thumb Bass
441	0	0	38	Slap Bass 2
442	0	43	38	Velocity Switch Slap
443	0	0	39	Synth Bass 1
444	0	18	39	Synth Bass 1 Dark
445	0	20	39	Fast Resonant Bass
446	0	24	39	Acid Bass
447	0	35	39	Clavi Bass
448	0	40	39	Techno Synth Bass
449	0	64	39	Orbiter
450	0	65	39	Square Bass
451	0	66	39	Rubber Bass
452	0	96	39	Hammer
453	0	0	40	Synth Bass 2
454	0	6	40	Mellow Synth Bass
455	0	12	40	Sequenced Bass
456	0	18	40	Click Synth Bass
457	0	19	40	Synth Bass 2 Dark
458	0	32	40	Smooth Synth Bass
459	0	40	40	Modular Synth Bass
460	0	41	40	DX Bass
461	0	64	40	X Wire Bass
XG STRINGS				
462	0	0	41	Violin
463	0	8	41	Slow Violin
464	0	0	42	Viola
465	0	0	43	Cello
466	0	0	44	Contrabass
467	0	0	45	Tremolo Strings
468	0	8	45	Slow Tremolo Strings
469	0	40	45	Suspense Strings
470	0	0	46	Pizzicato Strings
471	0	0	47	Orchestral Harp
472	0	0	48	Timpani
XG ENSEMBLE				
473	0	0	49	Strings 1
474	0	3	49	Stereo Strings
475	0	8	49	Slow Strings
476	0	24	49	Arco Strings
477	0	35	49	60s Strings
478	0	40	49	Orchestra 1
479	0	41	49	Orchestra 2
480	0	42	49	Tremolo Orchestra
481	0	45	49	Velocity Strings
482	0	0	50	Strings 2
483	0	3	50	Stereo Slow Strings
484	0	8	50	Legato Strings
485	0	40	50	Warm Strings
486	0	41	50	Kingdom

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
487	0	64	50	70s Strings
488	0	65	50	Strings 3
489	0	0	51	Synth Strings 1
490	0	27	51	Resonant Strings
491	0	64	51	Synth Strings 4
492	0	65	51	Synth Strings 5
493	0	0	52	Synth Strings 2
494	0	0	53	Choir Aahs 1
495	0	3	53	Stereo Choir
496	0	32	53	Mellow Choir
497	0	16	53	Choir Aahs 2
498	0	40	53	Choir Strings
499	0	0	54	Voice Oohs
500	0	0	55	Synth Voice 1
501	0	40	55	Synth Voice 2
502	0	41	55	Choral
503	0	64	55	Analog Voice
504	0	0	56	Orchestra Hit 1
505	0	35	56	Orchestra Hit 2
506	0	64	56	Impact
XG BRASS				
507	0	0	57	Trumpet 1
508	0	16	57	Trumpet 2
509	0	17	57	Bright Trumpet
510	0	32	57	Warm Trumpet
511	0	0	58	Trombone 1
512	0	18	58	Trombone 2
513	0	0	59	Tuba 1
514	0	16	59	Tuba 2
515	0	0	60	Muted Trumpet
516	0	0	61	French Horn 1
517	0	6	61	French Horn Solo
518	0	32	61	French Horn 2
519	0	37	61	Horn Orchestra
520	0	0	62	Brass Section 1
521	0	35	62	Trumpet & Trombone Section
522	0	40	62	Brass Section 2
523	0	41	62	High Brass
524	0	42	62	Mellow Brass
525	0	0	63	Synth Brass 1
526	0	12	63	Quack Brass
527	0	20	63	Resonant Synth Brass
528	0	24	63	Poly Brass
529	0	27	63	Synth Brass 3
530	0	32	63	Jump Brass
531	0	45	63	Analog Velocity Brass 1
532	0	64	63	Analog Brass 1
533	0	0	64	Synth Brass 2
534	0	18	64	Soft Brass
535	0	40	64	Synth Brass 4
536	0	41	64	Choir Brass
537	0	45	64	Analog Velocity Brass 2
538	0	64	64	Analog Brass 2
XG REED				
539	0	0	65	Soprano Sax
540	0	0	66	Alto Sax
541	0	40	66	Sax Section
542	0	43	66	Hyper Alto Sax
543	0	0	67	Tenor Sax 1
544	0	40	67	Breathy Tenor Sax
545	0	41	67	Soft Tenor Sax
546	0	64	67	Tenor Sax 2
547	0	0	68	Baritone Sax
548	0	0	69	Oboe
549	0	0	70	English Horn
550	0	0	71	Bassoon

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
551	0	0	72	Clarinet
552	0	0	73	Piccolo
553	0	0	74	Flute
554	0	0	75	Recorder
555	0	0	76	Pan Flute
556	0	0	77	Blown Bottle
557	0	0	78	Shakuhachi
558	0	0	79	Whistle
559	0	0	80	Ocarina
XG SYNTH LEAD				
560	0	0	81	Square Lead 1
561	0	6	81	Square Lead 2
562	0	8	81	LM Square
563	0	18	81	Hollow
564	0	19	81	Shroud
565	0	64	81	Mellow
566	0	65	81	Solo Sine
567	0	66	81	Sine Lead
568	0	0	82	Sawtooth Lead 1
569	0	6	82	Sawtooth Lead 2
570	0	8	82	Thick Sawtooth
571	0	18	82	Dynamic Sawtooth
572	0	19	82	Digital Sawtooth
573	0	20	82	Big Lead
574	0	24	82	Heavy Synth
575	0	25	82	Waspy Synth
576	0	40	82	Pulse Sawtooth
577	0	41	82	Dr. Lead
578	0	45	82	Velocity Lead
579	0	96	82	Sequenced Analog
580	0	0	83	Calliope Lead
581	0	65	83	Pure Lead
582	0	0	84	Chiff Lead
583	0	64	84	Rubby
584	0	0	85	Charang Lead
585	0	64	85	Distorted Lead
586	0	65	85	Wire Lead
587	0	0	86	Voice Lead
588	0	24	86	Synth Aahs
589	0	64	86	Vox Lead
590	0	0	87	Fifths Lead
591	0	35	87	Big Five
592	0	0	88	Bass & Lead
593	0	16	88	Big & Low
594	0	64	88	Fat & Perky
595	0	65	88	Soft Whirl
XG SYNTH PAD				
596	0	0	89	New Age Pad
597	0	64	89	Fantasy
598	0	0	90	Warm Pad
599	0	16	90	Thick Pad
600	0	17	90	Soft Pad
601	0	18	90	Sine Pad
602	0	64	90	Horn Pad
603	0	65	90	Rotary Strings
604	0	0	91	Poly Synth Pad
605	0	64	91	Poly Pad 80
606	0	65	91	Click Pad
607	0	66	91	Analog Pad
608	0	67	91	Square Pad
609	0	0	92	Choir Pad
610	0	64	92	Heaven
611	0	66	92	Itopia
612	0	67	92	CC Pad
613	0	0	93	Bowed Pad
614	0	64	93	Glacier

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
615	0	65	93	Glass Pad
616	0	0	94	Metallic Pad
617	0	64	94	Tine Pad
618	0	65	94	Pan Pad
619	0	0	95	Halo Pad
620	0	0	96	Sweep Pad
621	0	20	96	Shwimmer
622	0	27	96	Converge
623	0	64	96	Polar Pad
624	0	0	96	Celestial
XG SYNTH EFFECTS				
625	0	0	97	Rain
626	0	45	97	Clavi Pad
627	0	64	97	Harmo Rain
628	0	65	97	African Wind
629	0	66	97	Carib
630	0	0	98	Sound Track
631	0	27	98	Prologue
632	0	64	98	Ancestral
633	0	0	99	Crystal
634	0	12	99	Synth Drum Comp
635	0	14	99	Popcorn
636	0	18	99	Tiny Bells
637	0	35	99	Round Glockenspiel
638	0	40	99	Glockenspiel Chimes
639	0	41	99	Clear Bells
640	0	42	99	Chorus Bells
641	0	64	99	Synth Mallet
642	0	65	99	Soft Crystal
643	0	66	99	Loud Glockenspiel
644	0	67	99	Christmas Bells
645	0	68	99	Vibraphone Bells
646	0	69	99	Digital Bells
647	0	70	99	Air Bells
648	0	71	99	Bell Harp
649	0	72	99	Gamelimba
650	0	0	100	Atmosphere
651	0	18	100	Warm Atmosphere
652	0	19	100	Hollow Release
653	0	40	100	Nylon Electric Piano
654	0	64	100	Nylon Harp
655	0	65	100	Harp Vox
656	0	66	100	Atmosphere Pad
657	0	67	100	Planet
658	0	0	101	Brightness
659	0	64	101	Fantasy Bells
660	0	96	101	Smokey
661	0	0	102	Goblins
662	0	64	102	Goblins Synth
663	0	65	102	Creeper
664	0	66	102	Ring Pad
665	0	67	102	Ritual
666	0	68	102	To Heaven
667	0	70	102	Night
668	0	71	102	Glisten
669	0	96	102	Bell Choir
670	0	0	103	Echoes 1
671	0	8	103	Echoes 2
672	0	14	103	Echo Pan
673	0	64	103	Echo Bells
674	0	65	103	Big Pan
675	0	66	103	Synth Piano
676	0	67	103	Creation
677	0	68	103	Stardust
678	0	69	103	Resonant & Panning
679	0	0	104	Sci-Fi

Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
680	0	64	104	Starz
XG WORLD				
681	0	0	105	Sitar 1
682	0	35	105	Sitar 2
683	0	32	105	Detuned Sitar
684	0	97	105	Tamboura
685	0	0	112	Shanai 1
686	0	64	112	Shanai 2
687	0	96	112	Pungi
688	0	0	106	Banjo
689	0	28	106	Muted Banjo
690	0	0	109	Kalimba
691	0	0	110	Bagpipe
692	0	0	111	Fiddle
XG PERCUSSIVE				
693	0	0	113	Tinkle Bell
694	0	96	113	Bonang
695	0	97	113	Altair
696	0	98	113	Gamelan Gongs
697	0	99	113	Stereo Gamelan Gongs
698	0	100	113	Rama Cymbal
699	0	101	113	Asian Bells
700	0	0	114	Agogo
701	0	0	115	Steel Drums
702	0	97	115	Glass Percussion
703	0	98	115	Thai Bells
704	0	0	116	Woodblock
705	0	96	116	Castanets
706	0	0	117	Taiko Drum
707	0	96	117	Gran Cassa
708	0	0	118	Melodic Tom 1
709	0	64	118	Melodic Tom 2
710	0	65	118	Real Tom
711	0	66	118	Rock Tom
712	0	0	119	Synth Drum
713	0	64	119	Analog Tom
714	0	65	119	Electronic Percussion
715	0	0	120	Reverse Cymbal
XG SOUND EFFECTS				
716	0	0	121	Fret Noise
717	0	0	122	Breath Noise
718	0	0	123	Seashore
719	0	0	124	Bird Tweet 1
720	0	0	125	Telephone Ring 1
721	0	0	126	Helicopter
722	0	0	127	Applause
723	0	0	128	Gunshot
724	64	0	1	Cutting Noise 1
725	64	0	2	Cutting Noise 2
726	64	0	4	String Slap
727	64	0	17	Flute Key Click
728	64	0	33	Shower
729	64	0	34	Thunder
730	64	0	35	Wind
731	64	0	36	Stream
732	64	0	37	Bubble
733	64	0	38	Feed
734	64	0	49	Dog
735	64	0	50	Horse
736	64	0	51	Bird Tweet 2
737	64	0	56	Maou
738	64	0	65	Phone Call
739	64	0	66	Door Squeak
740	64	0	67	Door Slam
741	64	0	68	Scratch Cut
742	64	0	69	Scratch Split



Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
743	64	0	70	Wind Chime
744	64	0	71	Telephone Ring 2
745	64	0	81	Car Engine Ignition
746	64	0	82	Car Tires Squeal
747	64	0	83	Car Passing
748	64	0	84	Car Crash
749	64	0	85	Siren
750	64	0	86	Train
751	64	0	87	Jet Plane
752	64	0	88	Starship
753	64	0	89	Burst
754	64	0	90	Roller Coaster
755	64	0	91	Submarine
756	64	0	97	Laugh
757	64	0	98	Scream
758	64	0	99	Punch
759	64	0	100	Heartbeat
760	64	0	101	Footsteps
761	64	0	113	Machine Gun
762	64	0	114	Laser Gun
763	64	0	115	Explosion
764	64	0	116	Firework

NOTE 1

- Selecting a Voice number between 253 and 298 will turn on Arpeggio.
- Selecting a Voice number with an asterisk (*) will turn on Dual.
- Selecting a Voice number with two asterisks (**) will turn on Harmony.
- These Voice numbers cannot be selected via MIDI messages from a computer.

Drum Kit List


• The MIDI Note is actually one or two octave(s) lower than keyboard Note (see Default Octave column). For example, in "233: Standard Kit 1", the "Seq Click H" (Note C1) corresponds to (Note C0: Note# 24).

-  Same as Standard Kit 1
-  No Sound

	Voice No.				24	25	26	27
	MSB (0-127) / LSB (0-127) / PC (1-128)				000/116/117	126/000/116	126/000/117	126/000/40
	Keyboard		MIDI		Tabla	Tabla Kit 1	Tabla Kit 2	Indian Kit 1
	Note #	Note	Note #	Note				
	25	C# 0	13	C# -1				
	26	D 0	14	D -1				
	27	D# 0	15	D# -1				
E0	28	E 0	16	E -1				
F0	29	F 0	17	F -1				
F#0	30	F# 0	18	F# -1				
G0	31	G 0	19	G -1				
G#0	32	G# 0	20	G# -1				
A0	33	A 0	21	A -1				
A#0	34	A# 0	22	A# -1				
B0	35	B 0	23	B -1				
C1	36	C 1	24	C 0				
C#1	37	C# 1	25	C# 0				
D1	38	D 1	26	D 0				
D#1	39	D# 1	27	D# 0				
E1	40	E 1	28	E 0				
F1	41	F 1	29	F 0				
F#1	42	F# 1	30	F# 0				
G1	43	G 1	31	G 0				
G#1	44	G# 1	32	G# 0				
A1	45	A 1	33	A 0				
A#1	46	A# 1	34	A# 0				
B1	47	B 1	35	B 0				
C2	48	C 2	36	C 1				
C#2	49	C# 2	37	C# 1				
D2	50	D 2	38	D 1				
D#2	51	D# 2	39	D# 1				
E2	52	E 2	40	E 1				
F2	53	F 2	41	F 1				
F#2	54	F# 2	42	F# 1				
G2	55	G 2	43	G 1				
G#2	56	G# 2	44	G# 1				
A2	57	A 2	45	A 1				
A#2	58	A# 2	46	A# 1				
B2	59	B 2	47	B 1				
C3	60	C 3	48	C 2				
C#3	61	C# 3	49	C# 2				
D3	62	D 3	50	D 2				
D#3	63	D# 3	51	D# 2				
E3	64	E 3	52	E 2				
F3	65	F 3	53	F 2				
F#3	66	F# 3	54	F# 2				
G3	67	G 3	55	G 2				
G#3	68	G# 3	56	G# 2				
A3	69	A 3	57	A 2				
A#3	70	A# 3	58	A# 2				
B3	71	B 3	59	B 2				
C4	72	C 4	60	C 3				
C#4	73	C# 4	61	C# 3				
D4	74	D 4	62	D 3				
D#4	75	D# 4	63	D# 3				
E4	76	E 4	64	E 3				
F4	77	F 4	65	F 3				
F#4	78	F# 4	66	F# 3				
G4	79	G 4	67	G 3				
G#4	80	G# 4	68	G# 3				
A4	81	A 4	69	A 3				
A#4	82	A# 4	70	A# 3				
B4	83	B 4	71	B 3				
C5	84	C 5	72	C 4				
C#5	85	C# 5	73	C# 4				
D5	86	D 5	74	D 4				
D#5	87	D# 5	75	D# 4				
E5	88	E 5	76	E 4				
F5	89	F 5	77	F 4				
F#5	90	F# 5	78	F# 4				
G5	91	G 5	79	G 4				
G#5	92	G# 5	80	G# 4				
A5	93	A 5	81	A 4				
A#5	94	A# 5	82	A# 4				
B5	95	B 5	83	B 4				
C6	96	C 6	84	C 5				
C#6	97	C# 6	85	C# 5				
D6	98	D 6	86	D 5				
D#6	99	D# 6	87	D# 5				
E6	100	E 6	88	E 5				
F6	101	F 6	89	F 5				
F#6	102	F# 6	90	F# 5				
G6	103	G 6	91	G 5				



Drum Kit List

• The MIDI Note is actually one or two octave(s) lower than keyboard Note (see Default Octave column). For example, in "233: Standard Kit 1", the "Seq Click H" (Note C1) corresponds to (Note C0: Note# 24).

•  Same as Standard Kit 1

•  No Sound

		Voice No.				28	29	30
		MSB (0-127) / LSB (0-127) / PC (1-128)				126/000/115	126/000/033	126/000/112
		Keyboard		MIDI		Indian Kit 2	Indian Mix Kit	Animal Kit
		Note #	Note	Note #	Note			
		25	C# 0	13	C# -1		Zarb Back mf	
		26	D 0	14	D -1		Zarb Tom f	
		27	D# 0	15	D# -1	Indian Hand Clap 2	Zarb Eshareh	
E0		28	E 0	16	E -1	Dafli Open	Zarb Whipping	
F0		29	F 0	17	F -1	Dafli Slap	Tombak Tom f	
	F#0	30	F# 0	18	F# -1	Dafli Rim	Neghareh Tom f	
G0		31	G 0	19	G -1	Duff Open	Tombak Back f	
	G#0	32	G# 0	20	G# -1	Duff Slap	Neghareh Back f	
A0		33	A 0	21	A -1	Duff Rim	Tombak Snap f	
	A#0	34	A# 0	22	A# -1	Hatheli Long	Neghareh Pelang f	
B0		35	B 0	23	B -1	Hatheli Short	Tombak Trill	
C1		36	C 1	24	C 0	Baya ge	Kick T9 2	
	C#1	37	C# 1	25	C# 0	Baya Ke	Clap T9	
D1		38	D 1	26	D 0	Baya Ghe	Kick T9 4	
	D#1	39	D# 1	27	D# 0	Baya Ka	Snare T8 5	
E1		40	E 1	28	E 0	Tabla Na	Snare T8 1	
F1		41	F 1	29	F 0	Tabla Tin	Hi-Hat Close T8 1	
	F#1	42	F# 1	30	F# 0	Tablabaya Dha	Hi-Hat Open T9	
G1		43	G 1	31	G 0	Dhol 1 Open	Bass Drum Soft L	
	G#1	44	G# 1	32	G# 0	Dhol 1 Slap	Gran Cassa	
A1		45	A 1	33	A 0	Dhol 1 Mute	Gran Cassa Mute	
	A#1	46	A# 1	34	A# 0	Dhol 1 Open Slap	Band Snare 1	
B1		47	B 1	35	B 0	Dhol 1 Roll	Band Snare 2	
C2		48	C 2	36	C 1	DanDia Short	Hand Cymbal 1	
	C#2	49	C# 2	37	C# 1	DanDia Lowng	Shaker	
D2		50	D 2	38	D 1	Chutki	Snare Soft	
	D#2	51	D# 2	39	D# 1	Chipri	Conga H Mute	
E2		52	E 2	40	E 1	Khanjira Open	Riq Tish	
F2		53	F 2	41	F 1	Khanjira Slap	Riq Snouj 2	
	F#2	54	F# 2	42	F# 1	Khanjira Mute	Riq Roll	
G2		55	G 2	43	G 1	Khanjira Bendup	Riq Snouj 1	
	G#2	56	G# 2	44	G# 1	Khanjira Benddown	Riq Sak	
A2		57	A 2	45	A 1	Dholak 1 Open	Riq Snouj 3	
	A#2	58	A# 2	46	A# 1	Dholak 1 Mute	Riq Snouj 4	
B2		59	B 2	47	B 1	Dholak 1 Slap	Luo big	
C3		60	C 3	48	C 2	Dhol 2 Open	Cavasa House	Rooster
	C#3	61	C# 3	49	C# 2	Dhol 2 Slap	Maracas Slur	
D3		62	D 3	50	D 2	Dhol 2 Rim	Dhol Baya Open	Elephant
	D#3	63	D# 3	51	D# 2	Mridangam Na	Dhol Baya Mute	
E3		64	E 3	52	E 2	Mridangam Din	Dhol Chatti Open 1	Horse
F3		65	F 3	53	F 2	Mridangam Ki	Dhol Chatti Open 2	Cricket
	F#3	66	F# 3	54	F# 2	Mridangam Ta	Dhol Chatti Mute	
G3		67	G 3	55	G 2	Mridangam Chapu	Dhol Chatti Edge	Cow
	G#3	68	G# 3	56	G# 2	Mridangam Low Close	Dhol Body Click	
A3		69	A 3	57	A 2	Mridangam Low Open	Dholak Low Dhoom	Tiger
	A#3	70	A# 3	58	A# 2	Chimta Normal	Dholak Low Dum	
B3		71	B 3	59	B 2	Chimta Ring	Dholak Low Kath	Rattlesnake
C4		72	C 4	60	C 3	Dholki High Open	Dholak Low Dub	Monkeys
	C#4	73	C# 4	61	C# 3	Dholki High Mute	Dholak Low Gamak	
D4		74	D 4	62	D 3	Dholki Low Open	Dholak Low Ghissa	Crow
	D#4	75	D# 4	63	D# 3	Dholki High Slap	Dholak High Ta	
E4		76	E 4	64	E 3	Dholki Low Slide	Dholak High Na	
F4		77	F 4	65	F 3	Khol Open	Dholak High Skin	
	F#4	78	F# 4	66	F# 3	Khol Slide	Dholak High Chpi	
G4		79	G 4	67	G 3	Khol Mute	Dholak High Slap	
	G#4	80	G# 4	68	G# 3	Manjira Open	Dholak High Chilla	
A4		81	A 4	69	A 3	Manjira Close	Dholak 2 Open	
	A#4	82	A# 4	70	A# 3	Jhanji Open	Dholak 2 Slide	
B4		83	B 4	71	B 3	Jhanji Close	Dholak 2 Rim 1	
C5		84	C 5	72	C 4	Mondira Open	Dholak 2 Rim 2	
	C#5	85	C# 5	73	C# 4	Mondira Close	Dholak 2 Ring	
D5		86	D 5	74	D 4	Indian Bhangra Scat 1	Dholak 2 Slap	
	D#5	87	D# 5	75	D# 4	Indian Bhangra Scat 2	Chutki	
E5		88	E 5	76	E 4	Indian Bhangra Scat 3	Chipri	
F5		89	F 5	77	F 4	Indian Bhangra Scat 4	Dafli Open	
	F#5	90	F# 5	78	F# 4	Khomokh Normal	Dafli Slap	
G5		91	G 5	79	G 4	Khomokh Mute	Dafli Rim	
	G#5	92	G# 5	80	G# 4	Khomokh Mitatk	Duff Open	
A5		93	A 5	81	A 4	Thavil Open	Duff Slap	
	A#5	94	A# 5	82	A# 4	Thavil Slap	Duff Rim	
B5		95	B 5	83	B 4	Thavil Mute	Hatheli Long	
C6		96	C 6	84	C 5	Khartaal	Hatheli Short	
	C#6	97	C# 6	85	C# 5	Dholak 2 Open	Manjira Open	
D6		98	D 6	86	D 5	Dholak 2 Slide	Manjira Close	
	D#6	99	D# 6	87	D# 5	Dholak 2 Rim 1	Jhanji Open	
E6		100	E 6	88	E 5	Dholak 2 Rim 2	Jhanji Close	
F6		101	F 6	89	F 5	Dholak 2 Ring	Mondira Open	
	F#6	102	F# 6	90	F# 5	Dholak 2 Slap	Mondira Close	
G6		103	G 6	91	G 5		Wind Chime	



- The MIDI Note is actually one or two octave(s) lower than keyboard Note (see Default Octave column). For example, in “233: Standard Kit 1”, the “Seq Click H” (Note C1) corresponds to (Note C0: Note# 24).
-  Same as Standard Kit 1
-  No Sound

	Voice No.				232	233	234	235	236
	MSB (0-127) / LSB (0-127) / PC (1-128)				127/000/088	127/000/001	127/000/002	127/000/009	127/000/017
	Keyboard		MIDI		Power Kit	Standard Kit 1	Standard Kit 2	Room Kit	Rock Kit
	Note #	Note	Note #	Note					
	25	C# 0	13	C# -1		Surdo Mute			
	26	D 0	14	D -1		Surdo Open			
	27	D# 0	15	D# -1		Hi Q			
E0	28	E 0	16	E -1		Whip Slap			
F0	29	F 0	17	F -1		Scratch H			
F#0	30	F# 0	18	F# -1		Scratch L			
G0	31	G 0	19	G -1		Finger Snap			
G#0	32	G# 0	20	G# -1		Click Noise			
A0	33	A 0	21	A -1		Metronome Click			
A#0	34	A# 0	22	A# -1		Metronome Bell			
B0	35	B 0	23	B -1		Seq Click L			
C1	36	C 1	24	C 0		Seq Click H			
C#1	37	C# 1	25	C# 0		Brush Tap			
D1	38	D 1	26	D 0		Brush Swirl			
D#1	39	D# 1	27	D# 0		Brush Slap			
E1	40	E 1	28	E 0		Brush Tap Swirl			
F1	41	F 1	29	F 0		Snare Roll			
F#1	42	F# 1	30	F# 0		Castanet			
G1	43	G 1	31	G 0	Snare Soft Power	Snare Soft	Snare Soft 2		Snare Noisy
G#1	44	G# 1	32	G# 0		Sticks			
A1	45	A 1	33	A 0	Kick Amb+	Bass Drum Soft			
A#1	46	A# 1	34	A# 0	Open Rim Power	Open Rim Shot	Open Rim Shot 2		
B1	47	B 1	35	B 0	Kick Power Open	Bass Drum Hard			Bass Drum H
C2	48	C 2	36	C 1	Kick Power Closed	Bass Drum	Bass Drum 2		Bass Drum Rock
C#2	49	C# 2	37	C# 1	Side Stick Power	Side Stick			
D2	50	D 2	38	D 1	Snare Power	Snare	Snare 2	Snare Room L	Snare Rock
D#2	51	D# 2	39	D# 1	Hand Clap Power	Hand Clap			
E2	52	E 2	40	E 1	Snare Rough	Snare Tight	Snare Tight 2	Snare Room H	Snare Rock Rim
F2	53	F 2	41	F 1	Tom Power 1	Floor Tom L		Tom Room 1	Tom Rock 1
F#2	54	F# 2	42	F# 1	Hi-Hat Closed Power	Hi-Hat Closed			
G2	55	G 2	43	G 1	Tom Power 2	Floor Tom H	Tom Room 2		Tom Rock 2
G#2	56	G# 2	44	G# 1	Hi-Hat Pedal Power	Hi-Hat Pedal			
A2	57	A 2	45	A 1	Tom Power 3	Low Tom	Tom Room 3		Tom Rock 3
A#2	58	A# 2	46	A# 1	Hi-Hat Open Power	Hi-Hat Open			
B2	59	B 2	47	B 1	Tom Power 4	Mid Tom L	Tom Room 4		Tom Rock 4
C3	60	C 3	48	C 2	Tom Power 5	Mid Tom H	Tom Room 5		Tom Rock 5
C#3	61	C# 3	49	C# 2	Crash Cymbal Acoustic 1	Crash Cymbal 1			
D3	62	D 3	50	D 2	Tom Power 6	High Tom	Tom Room 6		Tom Rock 6
D#3	63	D# 3	51	D# 2	Ride Cymbal Acoustic 1	Ride Cymbal 1			
E3	64	E 3	52	E 2	Chinese Cymbal Acoustic	Chinese Cymbal			
F3	65	F 3	53	F 2	Ride Cymbal Cup Acoustic	Ride Cymbal Cup			
F#3	66	F# 3	54	F# 2		Tambourine			
G3	67	G 3	55	G 2	Splash Cymbal Acoustic	Splash Cymbal			
G#3	68	G# 3	56	G# 2		Cowbell			
A3	69	A 3	57	A 2	Crash Cymbal Acoustic 2	Crash Cymbal 2			
A#3	70	A# 3	58	A# 2		Vibraslap			
B3	71	B 3	59	B 2	Ride Cymbal Acoustic 2	Ride Cymbal 2			
C4	72	C 4	60	C 3		Bongo H			
C#4	73	C# 4	61	C# 3		Bongo L			
D4	74	D 4	62	D 3		Conga H Mute			
D#4	75	D# 4	63	D# 3		Conga H Open			
E4	76	E 4	64	E 3		Conga L			
F4	77	F 4	65	F 3		Timbale H			
F#4	78	F# 4	66	F# 3		Timbale L			
G4	79	G 4	67	G 3		Agogo H			
G#4	80	G# 4	68	G# 3		Agogo L			
A4	81	A 4	69	A 3		Cabasa			
A#4	82	A# 4	70	A# 3		Maracas			
B4	83	B 4	71	B 3		Samba Whistle H			
C5	84	C 5	72	C 4		Samba Whistle L			
C#5	85	C# 5	73	C# 4		Guiro Short			
D5	86	D 5	74	D 4		Guiro Long			
D#5	87	D# 5	75	D# 4		Claves			
E5	88	E 5	76	E 4		Wood Block H			
F5	89	F 5	77	F 4		Wood Block L			
F#5	90	F# 5	78	F# 4		Cuica Mute			
G5	91	G 5	79	G 4		Cuica Open			
G#5	92	G# 5	80	G# 4		Triangle Mute			
A5	93	A 5	81	A 4		Triangle Open			
A#5	94	A# 5	82	A# 4		Shaker			
B5	95	B 5	83	B 4		Jingle Bells			
C6	96	C 6	84	C 5		Bell Tree			
C#6	97	C# 6	85	C# 5					
D6	98	D 6	86	D 5					
D#6	99	D# 6	87	D# 5					
E6	100	E 6	88	E 5					
F6	101	F 6	89	F 5					
F#6	102	F# 6	90	F# 5					
G6	103	G 6	91	G 5					

Drum Kit List

- The MIDI Note is actually one or two octave(s) lower than keyboard Note (see Default Octave column). For example, in "233: Standard Kit 1", the "Seq Click H" (Note C1) corresponds to (Note C0: Note# 24).
- Same as Standard Kit 1
- No Sound

	Voice No.				233	237	238	239	240
	MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/001		127/000/025	127/000/059	127/000/060	127/000/026	
	Keyboard Note #	MIDI Note	Keyboard Note #	MIDI Note	Standard Kit 1	Electronic Kit	T8 Kit	T9 Kit	Analog Kit
	25	C# 0	13	C# -1	Surdo Mute				
	26	D 0	14	D -1	Surdo Open				
	27	D# 0	15	D# -1	Hi Q				
E0	28	E 0	16	E -1	Whip Slap				
F0	29	F 0	17	F -1	Scratch H				
F#0	30	F# 0	18	F# -1	Scratch L				
G0	31	G 0	19	G -1	Finger Snap		Snare Hammer	Snare D'n'B	
G#0	32	G# 0	20	G# -1	Click Noise		Kick Zap Hard	Kick Break	
A0	33	A 0	21	A -1	Metronome Click		Snare Garage L	Snare Distortion	
A#0	34	A# 0	22	A# -1	Metronome Bell		Kick Tek Power	Kick Tek Power	
B0	35	B 0	23	B -1	Seq Click L		Kick Slimy	Kick Distortion RM	
C1	36	C 1	24	C 0	Seq Click H		Kick T8 1	Kick T9 2	
C#1	37	C# 1	25	C# 0	Brush Snap		Snare Analog CR	Snare Analog CR	
D1	38	D 1	26	D 0	Brush Swirl		Snare T8 4	Snare T9 5	
D#1	39	D# 1	27	D# 0	Brush Slap		Snare Clap Analog	Clap Analog Sm	
E1	40	E 1	28	E 0	Brush Tap Swirl	Reverse Cymbal	Snare T8 3	Snare T9 Gate 1	Reverse Cymbal
F1	41	F 1	29	F 0	Snare Roll		Tom T8 5	Snare Rock Roll Distortion	
F#1	42	F# 1	30	F# 0	Castanet	Hi Q 2	Snare T8 5	Snare T9 3	Hi Q 2
G1	43	G 1	31	G 0	Snare Soft	Snare Snappy Electronic	Kick T8 3	Snare T9 4	Snare Noisy 4
G#1	44	G# 1	32	G# 0	Sticks		Snare T8 4	Snare T9 Gate 2	
A1	45	A 1	33	A 0	Bass Drum Soft	Bass Drum H	Kick T8 2	Kick T9 4	Bass Drum H
A#1	46	A# 1	34	A# 0	Open Rim Shot		Snare T8 3	Snare T9 5	
B1	47	B 1	35	B 0	Bass Drum Hard	Bass Drum Rock	Kick Bass T8	Kick T9 1	Bass Drum Analog L
C2	48	C 2	36	C 1	Bass Drum	Bass Drum Gate	Kick T8 1	Kick T9 3	Bass Drum Analog H
C#2	49	C# 2	37	C# 1	Side Stick		Snare T8 Rim	Snare T9 Rim	Side Stick Analog
D2	50	D 2	38	D 1	Snare	Snare Noisy 2	Snare T8 2	Snare T9 1	Snare Analog 1
D#2	51	D# 2	39	D# 1	Hand Clap		Clap T9	Clap T9	
E2	52	E 2	40	E 1	Snare Tight	Snare Noisy 3	Snare T8 1	Snare T9 2	Snare Analog 2
F2	53	F 2	41	F 1	Floor Tom L	Tom Electronic 1	Tom T8 1	Tom T9 1	Tom Analog 1
F#2	54	F# 2	42	F# 1	Hi-Hat Closed		Hi-Hat Closed T8 2	Hi-Hat Closed T9	Hi-Hat Closed Analog 1
G2	55	G 2	43	G 1	Floor Tom H	Tom Electronic 2	Tom T8 2	Tom T9 2	Tom Analog 2
G#2	56	G# 2	44	G# 1	Hi-Hat Pedal		Hi-Hat Pedal T8	Hi-Hat Pedal T9	Hi-Hat Closed Analog 2
A2	57	A 2	45	A 1	Low Tom	Tom Electronic 3	Tom T8 3	Tom T9 3	Tom Analog 3
A#2	58	A# 2	46	A# 1	Hi-Hat Open		Hi-Hat Open T8 2	Hi-Hat Open T9	Hi-Hat Open Analog
B2	59	B 2	47	B 1	Mid Tom L	Tom Electronic 4	Tom T8 4	Tom T9 4	Tom Analog 4
C3	60	C 3	48	C 2	Mid Tom H	Tom Electronic 5	Tom T8 6	Tom T9 5	Tom Analog 5
C#3	61	C# 3	49	C# 2	Crash Cymbal 1		Crash T8	Crash T9	Crash Analog
D3	62	D 3	50	D 2	High Tom	Tom Electronic 6	Tom T8 7	Tom T9 6	Tom Analog 6
D#3	63	D# 3	51	D# 2	Ride Cymbal 1		Ride T9	Ride T9	
E3	64	E 3	52	E 2	Chinese Cymbal		Chinese Cymbal 2	Chinese Cymbal 2	
F3	65	F 3	53	F 2	Ride Cymbal Cup		Ride Cymbal Cup 2	Ride Cymbal Cup 2	
F#3	66	F# 3	54	F# 2	Tambourine		Tambourine RX5	Tambourine RX5	
G3	67	G 3	55	G 2	Splash Cymbal		Splash Cymbal Acoustic	Crash Cymbal 3	
G#3	68	G# 3	56	G# 2	Cowbell		Cowbell T8	Cowbell 1	Cowbell Analog
A3	69	A 3	57	A 2	Crash Cymbal 2		Crash Cymbal 4	Crash Cymbal 4	
A#3	70	A# 3	58	A# 2	Vibraslap			Cowbell T8	
B3	71	B 3	59	B 2	Ride Cymbal 2		Ride Cymbal 3	Ride Cymbal 3	
C4	72	C 4	60	C 3	Bongo H		Conga T8 5	Conga T8 5	
C#4	73	C# 4	61	C# 3	Bongo L		Conga T8 3	Conga T8 4	
D4	74	D 4	62	D 3	Conga H Mute		Conga T8 3	Conga Tip	Conga Analog H
D#4	75	D# 4	63	D# 3	Conga H Open		Conga T8 2	Conga Open Slap	Conga Analog M
E4	76	E 4	64	E 3	Conga L		Conga T8 1	Conga Open	Conga Analog L
F4	77	F 4	65	F 3	Timbale H				
F#4	78	F# 4	66	F# 3	Timbale L				
G4	79	G 4	67	G 3	Agogo H		Glass H	Analog Click	
G#4	80	G# 4	68	G# 3	Agogo L		Glass L	Conga T8 1	
A4	81	A 4	69	A 3	Cabasa				
A#4	82	A# 4	70	A# 3	Maracas		Maracas T8	Maracas Slur	Maracas 2
B4	83	B 4	71	B 3	Samba Whistle H		Fx Gun 2	Fx Gun 2	
C5	84	C 5	72	C 4	Samba Whistle L		Fx Gun 1	Fx Gun 1	
C#5	85	C# 5	73	C# 4	Guiro Short		Analog Shaker H	Scratch H 2	
D5	86	D 5	74	D 4	Guiro Long		Analog Shaker L	Scratch Down	
D#5	87	D# 5	75	D# 4	Claves		Claves T8	Hi Q 3	Claves 2
E5	88	E 5	76	E 4	Wood Block H		Hi Q 1	Hi Q 1	
F5	89	F 5	77	F 4	Wood Block L		Hi Q 2	Hi Q 2	
F#5	90	F# 5	78	F# 4	Cuica Mute	Scratch H	Scratch L	Scratch L	Scratch H
G5	91	G 5	79	G 4	Cuica Open	Scratch L	Scratch L 2	Scratch L 2	Scratch L
G#5	92	G# 5	80	G# 4	Triangle Mute				
A5	93	A 5	81	A 4	Triangle Open				
A#5	94	A# 5	82	A# 4	Shaker		Analog Shaker	Analog Shaker	
B5	95	B 5	83	B 4	Jingle Bells		Sleigh Bell		
C6	96	C 6	84	C 5	Bell Tree		Wind Chime	Wind Chime	
C#6	97	C# 6	85	C# 5			Snare Hip 1	Snare Piccolo	
D6	98	D 6	86	D 5			Snare Hip 2	Snare T8 5	
D#6	99	D# 6	87	D# 5			Snare Hip Gate	Snare Rock Roll	
E6	100	E 6	88	E 5			Snare Break	Snare Brush Mute	
F6	101	F 6	89	F 5			Kick Blip	Kick Blip Hard	
F#6	102	F# 6	90	F# 5			Snare Fx	Snare Jungle 1	
G6	103	G 6	91	G 5			Kick FX Hammer	Kick Sustain	



- The MIDI Note is actually one or two octave(s) lower than keyboard Note (see Default Octave column). For example, in “233: Standard Kit 1”, the “Seq Click H” (Note C1) corresponds to (Note C0: Note# 24).
-  Same as Standard Kit 1
-  No Sound

		Voice No.		233	241	242	243	244
		MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/001	127/000/113	127/000/033	127/000/041	127/000/049
		Keyboard		Standard Kit 1	Dance Kit	Jazz Kit	Brush Kit	Symphony Kit
		Note #	Note	Note #	Note			
		25	C# 0	13	C# -1	Surdo Mute		
		26	D 0	14	D -1	Surdo Open		
		27	D# 0	15	D# -1	Hi Q		
E0		28	E 0	16	E -1	Whip Slap		
F0		29	F 0	17	F -1	Scratch H		
	F#0	30	F# 0	18	F# -1	Scratch L		
G0		31	G 0	19	G -1	Finger Snap		
	G#0	32	G# 0	20	G# -1	Click Noise		
A0		33	A 0	21	A -1	Metronome Click		
	A#0	34	A# 0	22	A# -1	Metronome Bell		
B0		35	B 0	23	B -1	Seq Click L		
C1		36	C 1	24	C 0	Seq Click H		
	C#1	37	C# 1	25	C# 0	Brush Tap		
D1		38	D 1	26	D 0	Brush Swirl		
	D#1	39	D# 1	27	D# 0	Brush Slap		
E1		40	E 1	28	E 0	Brush Tap Swirl	Reverse Cymbal	
F1		41	F 1	29	F 0	Snare Roll		
	F#1	42	F# 1	30	F# 0	Castanet	Hi Q 2	
G1		43	G 1	31	G 0	Snare Soft	Snare Techno	Brush Slap 2
	G#1	44	G# 1	32	G# 0	Sticks		
A1		45	A 1	33	A 0	Bass Drum Soft	Kick Techno Q	Bass Drum Soft L
	A#1	46	A# 1	34	A# 0	Open Rim Shot	Rim Gate	
B1		47	B 1	35	B 0	Bass Drum Hard	Kick Techno L	Gran Cassa
C2		48	C 2	36	C 1	Bass Drum	Kick Techno	Gran Cassa Mute
	C#2	49	C# 2	37	C# 1	Side Stick	Side Stick Analog	
D2		50	D 2	38	D 1	Snare	Snare Clap	Snare Jazz L
	D#2	51	D# 2	39	D# 1	Hand Clap		Brush Slap 3
E2		52	E 2	40	E 1	Snare Tight	Snare Dry	Snare Jazz M
	F2	53	F 2	41	F 1	Floor Tom L	Tom Analog 1	Tom Jazz 1
F2		54	F# 2	42	F# 1	Hi-Hat Closed	Hi-Hat Closed Analog 3	Tom Brush 1
	F#2	55	G 2	43	G 1	Floor Tom H	Tom Analog 2	Tom Jazz 2
G2		56	G# 2	44	G# 1	Hi-Hat Pedal	Hi-Hat Closed Analog 4	Tom Brush 2
	G#2	57	A 2	45	A 1	Low Tom	Tom Analog 3	Tom Jazz 2
A2		58	A# 2	46	A# 1	Hi-Hat Open	Hi-Hat Open Analog 2	Tom Brush 3
	A#2	59	B 2	47	B 1	Mid Tom L	Tom Analog 4	Tom Jazz 3
B2		60	C 3	48	C 2	Mid Tom H	Tom Analog 5	Tom Brush 4
C3		61	C# 3	49	C# 2	Crash Cymbal 1	Crash Analog	Tom Jazz 4
	C#3	62	D 3	50	D 2	High Tom	Tom Analog 6	Tom Brush 5
D3		63	D# 3	51	D# 2	Ride Cymbal 1		Tom Jazz 5
	D#3	64	E 3	52	E 2	Chinese Cymbal		Tom Brush 6
E3		65	F 3	53	F 2	Ride Cymbal Cup		Tom Jazz 6
	F3	66	F# 3	54	F# 2	Tambourine		Hand Cymbal 1
F3		67	G 3	55	G 2	Splash Cymbal		Hand Cymbal 1 Short
	G3	68	G# 3	56	G# 2	Cowbell	Cowbell Analog	
A3		69	A 3	57	A 2	Crash Cymbal 2		
	A#3	70	A# 3	58	A# 2	Vibraslap		Hand Cymbal 2
B3		71	B 3	59	B 2	Ride Cymbal 2		Hand Cymbal 2 Short
C4		72	C 4	60	C 3	Bongo H		
	C#4	73	C# 4	61	C# 3	Bongo L		
D4		74	D 4	62	D 3	Conga H Mute	Conga Analog H	
	D#4	75	D# 4	63	D# 3	Conga H Open	Conga Analog M	
E4		76	E 4	64	E 3	Conga L	Conga Analog L	
F4		77	F 4	65	F 3	Timbale H		
	F#4	78	F# 4	66	F# 3	Timbale L		
G4		79	G 4	67	G 3	Agogo H		
	G#4	80	G# 4	68	G# 3	Agogo L		
A4		81	A 4	69	A 3	Cabasa		
	A#4	82	A# 4	70	A# 3	Maracas	Maracas 2	
B4		83	B 4	71	B 3	Samba Whistle H		
C5		84	C 5	72	C 4	Samba Whistle L		
	C#5	85	C# 5	73	C# 4	Guiro Short		
D5		86	D 5	74	D 4	Guiro Long		
	D#5	87	D# 5	75	D# 4	Claves	Claves 2	
E5		88	E 5	76	E 4	Wood Block H		
F5		89	F 5	77	F 4	Wood Block L		
	F#5	90	F# 5	78	F# 4	Cuica Mute	Scratch H	
G5		91	G 5	79	G 4	Cuica Open	Scratch L	
	G#5	92	G# 5	80	G# 4	Triangle Mute		
A5		93	A 5	81	A 4	Triangle Open		
	A#5	94	A# 5	82	A# 4	Shaker		
B5		95	B 5	83	B 4	Jingle Bells		
C6		96	C 6	84	C 5	Bell Tree		
	C#6	97	C# 6	85	C# 5		Turn Table Noise	
D6		98	D 6	86	D 5			
	D#6	99	D# 6	87	D# 5			
E6		100	E 6	88	E 5			
F6		101	F 6	89	F 5			
	F#6	102	F# 6	90	F# 5			
G6		103	G 6	91	G 5			

Drum Kit List

- The MIDI Note is actually one or two octave(s) lower than keyboard Note (see Default Octave column). For example, in "233: Standard Kit 1", the "Seq Click H" (Note C1) corresponds to (Note C0: Note# 24).
- Same as Standard Kit 1
- No Sound
- Actual keyboard notes of the SFX Kit 1 and 2 are one octave lower than the ones described in the list below.

	Voice No.				245	246	247	248
	MSB (0-127) / LSB (0-127) / PC (1-128)				126/000/001	126/000/002	126/000/021	126/000/022
	Keyboard		MIDI		SFX Kit 1	SFX Kit 2	Bass Drum Kit	Reverse Bass Drum Kit
	Note #	Note	Note #	Note				
	25	C# 0	13	C# -1			BD Electro	Reverse BD Electro
	26	D 0	14	D -1			BD Fx Gate	Reverse BD Fx Gate
	27	D# 0	15	D# -1			BD Hammer	Reverse BD Hammer
E0	28	E 0	16	E -1			BD Analog Power	Reverse BD Analog Power
F0	29	F 0	17	F -1			BD Analog Distortion 5	
F#0	30	F# 0	18	F# -1			BD Analog Distortion 6	Reverse BD Analog Distortion 6
G0	31	G 0	19	G -1			BD Analog Distortion 4	
G#0	32	G# 0	20	G# -1			BD Analog Distortion 3	Reverse BD Analog Distortion 3
A0	33	A 0	21	A -1			BD Analog Distortion 2	Reverse BD Analog Distortion 2
A#0	34	A# 0	22	A# -1			BD Analog Tight	Reverse BD Analog Tight
B0	35	B 0	23	B -1			BD Analog 94	Reverse BD Analog 94
C1	36	C 1	24	C 0			BD Analog Blip 2	Reverse BD Analog Blip 2
C#1	37	C# 1	25	C# 0			BD Analog Rubber 2	Reverse BD Analog Rubber 2
D1	38	D 1	26	D 0			BD Analog 93	Reverse BD Analog 93
D#1	39	D# 1	27	D# 0			BD Analog 90	Reverse BD Analog 90
E1	40	E 1	28	E 0			BD Analog 83	Reverse BD Analog 83
F1	41	F 1	29	F 0			BD Analog 82	Reverse BD Analog 82
F#1	42	F# 1	30	F# 0			BD Analog 92	
G1	43	G 1	31	G 0			BD Analog 91	Reverse BD Analog 91
G#1	44	G# 1	32	G# 0			BD Analog Deep	Reverse BD Analog Deep
A1	45	A 1	33	A 0			BD Analog Hard 2	
A#1	46	A# 1	34	A# 0			BD Analog Hard 1	Reverse BD Analog Hard 1
B1	47	B 1	35	B 0			BD Analog Blip 1	Reverse BD Analog Blip 1
C2	48	C 2	36	C 1	Cutting Noise 1	Phone Call	BD Analog Rubber 1	Reverse BD Analog Rubber 1
C#2	49	C# 2	37	C# 1	Cutting Noise 2	Door Squeak	BD Analog Loose	Reverse BD Analog Loose
D2	50	D 2	38	D 1		Door Slam	BD Synth 1	Reverse BD Synth 1
D#2	51	D# 2	39	D# 1	String Slap	Scratch Cut	BD Synth 2	Reverse BD Synth 2
E2	52	E 2	40	E 1		Scratch	BD Analog Distortion 1	Reverse BD Analog Distortion 1
F2	53	F 2	41	F 1		Wind Chime	Ripper	Reverse Ripper
F#2	54	F# 2	42	F# 1		Telephone Ring	BD Analog 70 L	
G2	55	G 2	43	G 1			BD Analog 70	Reverse BD Analog 70
G#2	56	G# 2	44	G# 1			BD Analog 80	Reverse BD Analog 80
A2	57	A 2	45	A 1			BD Analog 80 Long	
A#2	58	A# 2	46	A# 1			BD Dry	Reverse BD Dry
B2	59	B 2	47	B 1			BD Dry Hard	
C3	60	C 3	48	C 2			BD Room 1	
C#3	61	C# 3	49	C# 2			BD Soft	Reverse BD Soft
D3	62	D 3	50	D 2			BD Room 2	Reverse BD Room 2
D#3	63	D# 3	51	D# 2			BD Break Lo-fi 2	Reverse BD Break Lo-fi 2
E3	64	E 3	52	E 2	Flute Key Click	Car Engine Ignition	BD Break Lo-fi 1	Reverse BD Break Lo-fi 1
F3	65	F 3	53	F 2		Car Tires Squeal	BD & Hi-Hat Open	Reverse BD & Hi-Hat Open
F#3	66	F# 3	54	F# 2		Car Passing	BD Jungle 2	
G3	67	G 3	55	G 2		Car Crash	BD Jungle 1	
G#3	68	G# 3	56	G# 2		Siren	BD Jungle 3	Reverse BD Jungle 3
A3	69	A 3	57	A 2		Train	BD D'n'B 1	Reverse BD D'n'B 1
A#3	70	A# 3	58	A# 2		Jet Plane	BD D'n'B 2	Reverse BD D'n'B 2
B3	71	B 3	59	B 2		Starship	BD RX5 1	Reverse BD RX5 1
C4	72	C 4	60	C 3		Burst	BD RX5 2	Reverse BD RX5 2
C#4	73	C# 4	61	C# 3		Roller Coaster	BD Room 3	Reverse BD Room 3
D4	74	D 4	62	D 3		Submarine	BD Power Gate	Reverse BD Power Gate
D#4	75	D# 4	63	D# 3			BD R&B 1	Reverse BD R&B 1
E4	76	E 4	64	E 3			BD R&B 2	Reverse BD R&B 2
F4	77	F 4	65	F 3			BD Lo-fi	Reverse BD Lo-fi
F#4	78	F# 4	66	F# 3			BD Hip Deep	
G4	79	G 4	67	G 3			BD Break Deep	Reverse BD Break Deep
G#4	80	G# 4	68	G# 3	Shower	Laugh	BD Break Heavy	Reverse BD Break Heavy
A4	81	A 4	69	A 3	Thunder	Scream	BD Break Hard	Reverse BD Break Hard
A#4	82	A# 4	70	A# 3	Wind	Punch	Big Drum	Reverse Big Drum
B4	83	B 4	71	B 3	Stream	Heartbeat	Taiko Drum	Reverse Taiko Drum
C5	84	C 5	72	C 4	Bubble	Footsteps	Surdo Open	Reverse Surdo Open
C#5	85	C# 5	73	C# 4	Feed		Feet 2	Reverse Feet 2
D5	86	D 5	74	D 4			BD Industrial	Reverse Tom Industrial
D#5	87	D# 5	75	D# 4			Door Slam	Reverse Door Slam
E5	88	E 5	76	E 4			Punch	Reverse Punch
F5	89	F 5	77	F 4			Heart	
F#5	90	F# 5	78	F# 4			Feet 1	Reverse Feet 1
G5	91	G 5	79	G 4			BD Human	Reverse BD Human
G#5	92	G# 5	80	G# 4			BD Human Deep	Reverse BD Human Deep
A5	93	A 5	81	A 4			Vox Buh!	Reverse Vox Buh!
A#5	94	A# 5	82	A# 4			Vox Muh!	Reverse Vox Muh!
B5	95	B 5	83	B 4				
C6	96	C 6	84	C 5	Dog	Machine Gun		
C#6	97	C# 6	85	C# 5	Horse	Laser Gun		
D6	98	D 6	86	D 5	Bird Tweet	Explosion		
D#6	99	D# 6	87	D# 5		Firework		
E6	100	E 6	88	E 5				
F6	101	F 6	89	F 5				
F#6	102	F# 6	90	F# 5				
G6	103	G 6	91	G 5	Maou			

- The MIDI Note is actually one or two octave(s) lower than keyboard Note (see Default Octave column). For example, in “233: Standard Kit 1”, the “Seq Click H” (Note C1) corresponds to (Note C0: Note# 24).
-  Same as Standard Kit 1
-  No Sound
- Actual keyboard notes of the Arabic Kit are one octave higher than the ones described in the list below.

	Voice No.				233	249	150	251	252
	MSB (0-127) / LSB (0-127) / PC (1-128)				127/000/001	126/000/125	127/000/127	126/000/037	126/000/041
	Keyboard	MIDI			Standard Kit 1	China Kit 1	China Kit 2	Arabic Kit	Cuban Kit
Note #	Note	Note #	Note						
	25	C# 0	13	C# -1	Surdo Mute			Zarb Back mf	
	26	D 0	14	D -1	Surdo Open			Zarb Tom f	
	27	D# 0	15	D# -1	Hi Q			Zarb Eshareh	
E0	28	E 0	16	E -1	Whip Slap			Zarb Whipping	
F0	29	F 0	17	F -1	Scratch H			Tombak Tom f	
	30	F# 0	18	F# -1	Scratch L			Neghareh Tom f	
G0	31	G 0	19	G -1	Finger Snap			Tombak Back f	
	32	G# 0	20	G# -1	Click Noise			Neghareh Back f	
A0	33	A 0	21	A -1	Metronome Click			Tombak Snap f	
	34	A# 0	22	A# -1	Metronome Bell			Neghareh Pelang f	Conga H Tip
B0	35	B 0	23	B -1	Seq Click L	Da Cha		Tombak Trill	Conga H Heel
C1	36	C 1	24	C 0	Seq Click H	Da Gu mp		Khaligi Clap 1	Conga H Open
	37	C# 1	25	C# 0	Brush Swirl	Da Gu rim		Arabic Zalgouta Open	Conga H Mute
D1	38	D 1	26	D 0	Brush Swirl	Da Gu f		Khaligi Clap 2	Conga H Slap Open
	39	D# 1	27	D# 0	Brush Slap	Da Gu hand		Arabic Zalgouta Close	Conga H Slap
E1	40	E 1	28	E 0	Brush Tap Swirl	Da Gu Roll		Arabic Hand Clap	Conga H Slap Mute
F1	41	F 1	29	F 0	Snare Roll	Pai Gu 4		Tabel Tak 1	Conga L Tip
	42	F# 1	30	F# 0	Castanet	Pai Gu 4 High		Sagat 1	Conga L Heel
G1	43	G 1	31	G 0	Snare Soft	Pai Gu 3		Tabel Dom	Conga L Open
	44	G# 1	32	G# 0	Sticks	Pai Gu 3 High		Sagat 2	Conga L Mute
A1	45	A 1	33	A 0	Bass Drum Soft	Pai Gu 2		Tabel Tak 2	Conga L Slap Open
	46	A# 1	34	A# 0	Open Rim Shot	Pai Gu 2 High		Sagat 3	Conga L Slap
B1	47	B 1	35	B 0	Bass Drum Hard	Pai Gu 1		Riq Tik 3	Conga L Slide
C2	48	C 2	36	C 1	Bass Drum	Luo High 1		Riq Tik 2	Bongo H Open 1 finger
	49	C# 2	37	C# 1	Side Stick	Gong batter		Riq Tik Hard 1	Bongo H Open 3 finger
D2	50	D 2	38	D 1	Snare	Jin Luo		Riq Tik 1	Bongo H Rim
	51	D# 2	39	D# 1	Hand Clap	Luo High 2		Riq Tik Hard 2	Bongo H Tip
E2	52	E 2	40	E 1	Snare Tight	Luo Mid-Low		Riq Tik Hard 3	Bongo H Heel
F2	53	F 2	41	F 1	Floor Tom L	Luo		Riq Tish	Bongo H Slap
	54	F# 2	42	F# 1	Hi-Hat Closed	Jin Luo Low		Riq Snouj 2	Bongo L Open 1 finger
G2	55	G 2	43	G 1	Floor Tom H	Da Cha		Riq Roll	Bongo L Open 3 finger
	56	G# 2	44	G# 1	Hi-Hat Pedal	Da Cha effect		Riq Snouj 1	Bongo L Rim
A2	57	A 2	45	A 1	Low Tom	Zhong Cha		Riq Sak	Bongo L Tip
	58	A# 2	46	A# 1	Hi-Hat Open	Xiao Cha effect		Riq Snouj 3	Bongo L Heel
B2	59	B 2	47	B 1	Mid Tom L	Xiao Cha		Riq Snouj 4	Bongo L Slap
C3	60	C 3	48	C 2	Mid Tom H	Mang Luo Low		Riq Tak 1	Timbale L Open
	61	C# 3	49	C# 2	Crash Cymbal 1	Mang Luo Mid		Riq Brass 1	
D3	62	D 3	50	D 2	High Tom	Qing		Riq Tak 2	
	63	D# 3	51	D# 2	Ride Cymbal 1	Finger Bell		Riq Brass 2	
E3	64	E 3	52	E 2	Chinese Cymbal	Luo big		Riq Dom	
F3	65	F 3	53	F 2	Ride Cymbal Cup	Mu Yu Low		Katem Tak Doff	Paila L
	66	F# 3	54	F# 2	Tambourine	Mu Yu Mid-Low		Katem Dom	Timbale H Open
G3	67	G 3	55	G 2	Splash Cymbal	Mu Yu Mid		Katem Sak 1	
	68	G# 3	56	G# 2	Cowbell	Mu Yu High		Katem Tak 1	
A3	69	A 3	57	A 2	Crash Cymbal 2	Nan Bang Zi Roll		Katem Sak 2	
	70	A# 3	58	A# 2	Vibraslap	Nan Bang Zi		Katem Tak 2	
B3	71	B 3	59	B 2	Ride Cymbal 2	Ban Gu		Daholla Sak 2	Paila H
C4	72	C 4	60	C 3	Bongo H	Ban		Daholla Sak 1	Cowbell Top
	73	C# 4	61	C# 3	Bongo L	Ban Gu Roll		Daholla Tak 1	
D4	74	D 4	62	D 3	Conga H Mute	Chinese Opera Voice 1		Daholla Dom	
	75	D# 4	63	D# 3	Conga H Open	Chinese Opera Voice 2		Daholla Tak 2	
E4	76	E 4	64	E 3	Conga L	Chinese Opera Voice 3		Tablah Prok	Guiro Short
F4	77	F 4	65	F 3	Timbale H	Yun Luo F4		Tablah Dom 2	Guiro Long
	78	F# 4	66	F# 3	Timbale L	Yun Luo F#4		Tablah Roll of Edge	
G4	79	G 4	67	G 3	Agogo H	Yun Luo G4	Dagu Mute	Tablah Tak Finger 4	
	80	G# 4	68	G# 3	Agogo L	Yun Luo G#4	Zhongcha Mute	Tablah Tak Trill 1	Tambourine
A4	81	A 4	69	A 3	Cabasa	Yun Luo A4	Dagu Heavy	Tablah Tak Finger 3	
	82	A# 4	70	A# 3	Maracas	Yun Luo A#4	Zhongcha Open	Tablah Tak Trill 2	
B4	83	B 4	71	B 3	Samba Whistle H	Yun Luo B4	Paigu Middle	Tablah Tak Finger 2	
C5	84	C 5	72	C 4	Samba Whistle L	Yun Luo C5	Paigu Low	Tablah Tak Finger 1	Maracas
	85	C# 5	73	C# 4	Guiro Short	Yun Luo C#5	Xiaocha Mute	Tablah Tik 2	Shaker
D5	86	D 5	74	D 4	Guiro Long	Yun Luo D5	Bangu	Tablah Tik 4	Cabasa
	87	D# 5	75	D# 4	Claves	Yun Luo D#5	Xiaocha Open	Tablah Tik 3	
E5	88	E 5	76	E 4	Wood Block H	Yun Luo E5	Bangzi	Tablah Tik 1	
F5	89	F 5	77	F 4	Wood Block L	Yun Luo F5	Muyu Low	Tablah Tak 3	
	90	F# 5	78	F# 4	Cuica Mute	Yun Luo F#5	Zhongluo Mute	Tablah Tak 1	
G5	91	G 5	79	G 4	Cuica Open	Yun Luo G5	Muyu Mid-Low	Tablah Tak 4	
	92	G# 5	80	G# 4	Triangle Mute	Yun Luo G#5	Zhongluo Open	Tablah Tak 2	
A5	93	A 5	81	A 4	Triangle Open	Yun Luo A5	Muyu Middle	Tablah Sak 2	
	94	A# 5	82	A# 4	Shaker	Yun Luo A#5	Xiaoluo Open	Tablah Tremolo	
B5	95	B 5	83	B 4	Jingle Bells	Yun Luo B5	Triangle Mute	Tablah Sak 1	
C6	96	C 6	84	C 5	Bell Tree	Yun Luo C6	Triangle Open	Tablah Dom 1	
	97	C# 6	85	C# 5					
D6	98	D 6	86	D 5					
	99	D# 6	87	D# 5					
E6	100	E 6	88	E 5					
F6	101	F 6	89	F 5					
	102	F# 6	90	F# 5					
G6	103	G 6	91	G 5					

Style List

Style No.	Style Name
INDIAN	
1	Dholly
2	ElectroRetro
3	SouthSoul
4	HaryanaFolk
5	SandGroove
6	GrooveEast
7	HouseTabla
8	Bollywood 1
9	Bollywood 2
10	Bollywood 3
11	Bollywood 4
12	IndianPop
13	HindiBallad
14	IndianWaltz 1
15	IndianWaltz 2
16	IndianDance 1
17	IndianDance 2
18	Tamil
19	Kerala
20	GoaGroove
21	GoanPop
22	Rajasthan
23	Dandiya
24	Garba
25	Bhangra 1
26	Bhangra 2
27	Boliyan
28	BaleBale
29	South
30	Bhajan 1
31	Bhajan 2
32	ModernQawwali
33	Qawwali
34	Gurbani
35	Prayer
8BEAT	
36	BritPopRock
37	8BeatModern
38	Cool8Beat
39	60sGuitarPop
40	8BeatAdria
41	60s8Beat
42	BubblegumPop
43	BritPopSwing
44	8Beat
45	OffBeat
46	60sRock
47	HardRock
48	RockShuffle
49	8BeatRock
16BEAT	
50	16Beat
51	PopShuffle 1
52	PopShuffle 2
53	GuitarPop
54	16BeatUptempo
55	KoolShuffle
56	JazzRock
57	HipHopLight
BALLAD	
58	70sGlamPiano
59	PopGuitarBallad
60	PianoBallad
61	LoveSong
62	6/8ModernEP
63	6/8SlowRock

Style No.	Style Name
64	6/8OrchestraBallad
65	OrganBallad
66	PopBallad
67	16BeatBallad 1
68	16BeatBallad 2
DANCE	
69	AgagBeat
70	WestCoastDance
71	ClubBeat
72	Electronica
73	FunkyHouse
74	ChartR&B
75	MellowHipHop
76	SoulR&B
77	R&BSoulBallad
78	Chillout
79	EuroTrance
80	Ibiza
81	DreamDance
82	NewHipHop
83	PopR&B
84	TrancePop
85	ChartPop
86	HouseMusik
87	SwingHouse
88	TechnoPolis
89	Clubdance
90	ClubLatin
91	Garage 1
92	Garage 2
93	TechnoParty
94	UKPop
95	HipHopGroove
96	HipShuffle
97	HipHopPop
DISCO	
98	ModernDisco
99	70sDisco 1
100	70sDisco 2
101	LatinDisco
102	DiscoPhilly
103	SaturdayNight
104	DiscoChocolate
105	DiscoHands
SWING&JAZZ	
106	BigBandFast
107	BigBandMedium
108	BigBandBallad
109	BigBandShuffle
110	AcousticJazz
111	AcidJazz
112	JazzClub
113	Swing 1
114	Swing 2
115	OrchestraSwing
116	Five/Four
117	JazzBallad
118	Dixieland
119	Ragtime
120	AfroCuban
121	Charleston
R&B	
122	BluesRock
123	Soul
124	DetroitPop 1
125	60sRock&Roll
126	6/8Soul

Style No.	Style Name
127	ModernR&B
128	CrocoTwist
129	Rock&Roll
130	DetroitPop 2
131	BoogieWoogie
132	ComboBoogie
133	6/8Blues
COUNTRY	
134	Country8Beat
135	CountryPop
136	CountrySwing
137	CountryBallad
138	Country2/4
139	CowboyBoogie
140	CountryShuffle
141	Bluegrass
LATIN	
142	BrazilianSamba
143	BossaNova
144	PopBossa
145	Forro
146	Sertanejo
147	Tijuana
148	Joropo
149	Parranda
150	Reggaeton
151	DiscoLatin
152	Mambo
153	Salsa
154	Beguine
155	GuitarRumba
156	RumbaFlamenco
157	RumbaIsland
158	Reggae
BALLROOM	
159	VienneseWaltz
160	EnglishWaltz
161	Slowfox
162	Foxtrot
163	Quickstep
164	Tango
165	Pasodoble
166	Samba
167	ChaChaCha
168	Rumba
169	Jive
TRADITIONAL	
170	USMarch
171	6/8March
172	GermanMarch
173	PolkaPop
174	OberkraienerPolka
175	Tarantella
176	Showtune
177	ChristmasSwing
178	ChristmasWaltz
179	ScottishReel
180	Hawaiian
181	PasoDuranguense
182	CumbiaGrupera
183	Saeidy
184	WehdaSaghira
185	Laff
186	IranianElec
187	Emarati
188	XiQingLuoGu
189	JingJuJieZou

Riyaz List

Style No.	Style Name
190	ModernDangdut
191	Keroncong
WALTZ	
192	ItalianWaltz
193	ValsMexicano
194	GuitarSerenade
195	SwingWaltz
196	JazzWaltz 1
197	JazzWaltz 2
198	CountryWaltz
199	OberkrainerWalzer
200	Musette
CHILDREN	
201	Learning2/4
202	Learning4/4
203	Learning6/8
204	Fun3/4
205	Fun4/4
PIANIST	
206	Stride
207	PianoBlues 1
208	PianoBlues 2
209	PianoRag
210	PianoRock&Roll
211	PianoBoogie
212	PianoJazzWaltz
213	PianoJazzBallad
214	Arpeggio
215	Musical
216	SlowRock
217	8BeatPianoBallad
218	PianoSwing

Riyaz No.	Riyaz Name
1	Teen Taal
2	Rupak Taal
3	Jhap Taal
4	Ek Taal
5	Chau Taal
6	Chachar Taal
7	Tilwada
8	Jhoomra
9	Adachau Taal
10	Deepchandi
11	Dadra
12	Keherwa
13	Garba
14	Bhajan
15	Punjabi
16	Tishram
17	Chatushram
18	Khandam
19	Mishram
20	Sankeernam

Song List

Song No.	Song Name	Composer
MAIN DEMO		
1	India	Original
2	Globe Pop	Original
3	Chillin	Original
VOICE DEMO		
4	Grand Piano Demo	Original
5	Sweet! Tenor Sax Demo	Original
6	Cool! Rotor Organ Demo	Original
7	Cool! Galaxy Electric Piano Demo	Original
8	Modern Harp & Sweet! Soprano Demo	Original
9	Power Kit Drum Demo	Original
10	Dance Kit Drum Demo	Original
11	Cuban Kit Percussion Demo	Original
RAGA SCALE		
12	Bilawal	Traditional
13	Khamaaj	Traditional
14	Bhairav	Traditional
15	Kalyan	Traditional
16	Asavari	Traditional
17	Kalyani	Traditional
18	Hamsadhvani	Traditional
19	Mohanam	Traditional
20	Hindolam	Traditional
21	Sankarabharanam	Traditional
22	Kafi	Traditional
23	Bhairavi	Traditional
24	Marwa	Traditional
25	Poorvi	Traditional
26	Todi	Traditional
PIANO SOLO		
27	Maple Leaf Rag	S. Joplin
28	Jeanie with the Light Brown Hair	S. C. Foster
29	The Last Rose of Summer	Traditional
30	Für Elise	L. v. Beethoven
31	Valse op.64-1 "Petit Chien"	F. Chopin
32	Turkish March	W. A. Mozart
33	Menuett/Beethoven	L. v. Beethoven
34	Andante grazioso (Sonate K.331)	W. A. Mozart
35	24 Preludes op.28-7	F. Chopin
36	Melodie (Album für die Jugend)	R. Schumann
37	Fröhlicher Landmann (Album für die Jugend)	R. Schumann
38	Von fremden Ländern und Menschen (Kinderszenen)	R. Schumann
39	Träumerei (Kinderszenen)	R. Schumann
40	Thema (Impromptus D.935-3)	F. Schubert
41	Menuett BWV Anh.116	J. S. Bach
42	Invention Nr.1	J. S. Bach
43	Gavotte/J. S. Bach	J. S. Bach
44	Arietta/Grieg	E. Grieg
45	To a Wild Rose	E. A. MacDowell
46	Tango/Albeniz	I. Albéniz
47	La Fille aux Cheveux de Lin	C. A. Debussy
48	La Chevaleresque	J. F. Burgmüller
49	Arabesque	J. F. Burgmüller
50	Pastorale	J. F. Burgmüller
51	Annie Laurie	Traditional
52	The Entertainer	S. Joplin
PIANO ENSEMBLE		
53	Amazing Grace	Traditional
54	Die Lorelei	F. Silcher
55	Piano Concerto No.21 2nd mov.	W. A. Mozart
56	Scarborough Fair	Traditional
57	Old Folks at Home	S. C. Foster

Song No.	Song Name	Composer
58	Londonderry Air	Traditional
59	Home Sweet Home	H. R. Bishop
60	Jesus bleibet meine Freude	J. S. Bach
61	Loch Lomond	Traditional
62	Twinkle Twinkle Little Star	Traditional
63	Three Blind Mice	Traditional
64	Believe Me If All Those Endearing Young Charms	Traditional
65	Nocturne op.9-2	F. Chopin
66	Etude op.10-3 "Chanson de l'adieu"	F. Chopin
67	Ave Maria/J. S. Bach - Gounod	J. S. Bach / C. F. Gounod
68	Menuett BWV Anh.114	J. S. Bach
69	Wenn ich ein Vöglein wär	Traditional
70	Der Vogelfänger bin ich ja	W. A. Mozart
71	Romanze (Serenade K.525)	W. A. Mozart
72	Ave Verum Corpus	W. A. Mozart
73	Liebesträume Nr.3	F. Liszt
74	Chanson du Toreador	G. Bizet
75	Frühlingslied	F. Mendelssohn
76	Ode to Joy	L. v. Beethoven
77	O Christmas Tree	Traditional
78	Deck the Halls	Traditional
79	Silent Night	F. Gruber
PIANO ACCOMPANIMENT		
80	Ep Ballad	Original
81	Boogie Woogie	Original
82	Rock Piano	Original
83	Salsa	Original
84	Country Piano	Original
85	Gospel R&B	Original
86	Medium Swing	Original
87	Jazz Waltz	Original
88	Medium Bossa	Original
89	Slow Rock	Original
CLASSICAL MELODIES		
90	Waltz (The Sleeping Beauty)	P. I. Tchaikovsky
91	Air (Orchestral Suite)	J. S. Bach
92	Minuetto/Boccherini	L. Boccherini
93	Siciliano/J. S. Bach	J. S. Bach
94	Menuet (L'Arlésienne)	G. Bizet
95	Slavonic Dances op.72-2	A. Dvořák
96	Largo (From the New World)	A. Dvořák
97	Pizzicato Polka	J. Strauss II
98	Romanze/Beethoven	L. v. Beethoven
99	Swan Lake	P. I. Tchaikovsky
100	Sicilienne/Fauré	G. Fauré
101	Méditation (Thaïs)	J. Massenet
102	Serenade/Haydn	F. J. Haydn
103	Grand March (Aida)	G. Verdi
104	Danza dell'Ore (La Gioconda)	A. Ponchielli
105	Le Cygne (Le Carnaval des Animaux)	C. Saint-Saëns
106	L'éléphant (Le Carnaval des Animaux)	C. Saint-Saëns
107	Fossiles (Le Carnaval des Animaux)	C. Saint-Saëns
108	Wachet auf, ruft uns die Stimme BWV 645	J. S. Bach
TRADITIONAL MELODIES		
109	Greensleeves	Traditional
110	Beautiful Dreamer	S. C. Foster
111	Ring de Banjo	S. C. Foster
112	O du lieber Augustin	Traditional
113	London Bridge	Traditional
114	Aura Lee	Traditional
115	Aloha Oe	Q. Liliuokalani

Arpeggio List

Arpeggio No.	Arpeggio Name
1	UpOct
2	DownOct
3	UpDwnOct
4	SynArp1
5	SynArp2
6	SynArp3
7	SynArp4
8	SyncEcho
9	PulsLine
10	StepLine
11	Random
12	Down&Up
13	SuperArp
14	AcidLine
15	TekEcho
16	VelGruv
17	Planet
18	Trance1
19	Trance2
20	Trance3
21	ChordAlt
22	SynChrd1
23	SynChrd2
24	Syncopa
25	Hybrid1
26	Hybrid2
27	Hybrid3
28	Hybrid4
29	Hybrid5
30	PfArp1
31	PfArp2
32	PfArp3
33	PfArp4
34	PfClub1
35	PfClub2
36	PfBallad
37	PfChd8th
38	EPArp
39	PfShuffle
40	PfRock
41	Clavi1
42	Clavi2
43	RocknPf
44	70RockPf
45	SlowflPf
46	SoulPf
47	ChordUp
48	ChdDance
49	LatinRck
50	Salsa1
51	Salsa2
52	Reggae1
53	Reggae2
54	Reggae3

Arpeggio No.	Arpeggio Name
55	6/8R&B
56	Gospel
57	BalladEP
58	Strum1
59	Strum2
60	Strum3
61	Strum4
62	Pickin1
63	Pickin2
64	Funky
65	GtrChrd1
66	GtrChrd2
67	GtrChrd3
68	GtrArp
69	FngrPck1
70	FngrPck2
71	CleanGtr
72	Slowfl
73	Samba1
74	Samba2
75	Spanish1
76	Spanish2
77	Harp1
78	Harp2
79	FngrBas1
80	FngrBas2
81	FngrBas3
82	CoolFunk
83	SlapBass
84	AcidBas1
85	AcidBas2
86	FunkyBas
87	CmbJazB1
88	CmbJazB2
89	CmbJazB3
90	NewR&BBs
91	HipHopBs
92	SmoothBs
93	DreamBas
94	TranceBs
95	LatinBas
96	Strings1
97	Strings2
98	Strings3
99	Strings4
100	StrngDwn
101	StrngUp
102	OrcheStr
103	Jupiter
104	Pizz1
105	Pizz2
106	BrasSec1
107	BrasSec2
108	BrasSec3

Arpeggio No.	Arpeggio Name
109	FunkBras
110	SoulReed
111	DiscoLd
112	SmoothPd
113	PercArp
114	Trill
115	Cresendo
116	DiscoCP
117	Perc1
118	Perc2
119	R&B
120	Funk1
121	Funk2
122	Funk3
123	Soul
124	CiscHip
125	Smooth
126	NewGospl
127	CmbJazz1
128	CmbJazz2
129	Bebop
130	JazzHop
131	FolkRock
132	Unplugge
133	HipHop
134	Trance
135	Dream
136	2 Step
137	ClubHs1
138	ClubHs2
139	EuroTek
140	House
141	Ibiza1
142	Ibiza2
143	Ibiza3
144	Garage
145	Samba
146	African
147	Latin
148	China
149	Indian
150	Arabic
151	TeenTalC
152	TeenTalD
153	TeenTalE
154	TeenTalF
155	TeenTalG
156	TeenTalA
157	Dadra C
158	Dadra D
159	Dadra E
160	Dadra F
161	Dadra G
162	Dadra A

Music Database List

MDB No.	MDB Name
INDIAN MOVIE	
1	Ghoom
2	Anna
3	Dance Up
4	Nain Tkt
5	BaratYad
6	Nazr Ja
7	Soniya
8	Des
9	Sapera
10	MareAnkh
11	Asha
12	Ladki
13	Ho Kal
14	Pratna
15	Naata
16	Darmeya
17	Raate Ye
18	Dewana
19	Cheeze
20	Nasha
21	Jai Shv
22	Raang
23	Akele
24	Mere Dil
25	Aaj Kal
26	Bade Dil
27	Nam Mera
28	Rani
29	Gale Se
30	Nee Am
31	Sapne Ek
32	Sanm Tuj
33	Zulfo
34	Pop Jia
35	Sham
36	Mere Man
37	Kabhi
38	Chal
39	Tujhe
40	Laung
41	Chand
42	Janm
43	Raat Din
44	Subha
45	Tera Pyr
46	Mera Snm
47	Suun
48	Nain Kjr
49	Nachoo
50	Kya Khna
ALL TIME HITS	
51	Jude Hey
52	New UK
53	MyLoving
54	All OK
55	Buttercp
56	JustCall
57	CheepChp
58	Daddy's
59	Dance?
60	Get Home
61	GtrWheel
62	HighTide
63	lWasBorn
64	Sailing
65	BluJeans

MDB No.	MDB Name
66	Holiday
67	Imagine
68	LoveMe
69	LetItBld
70	LdyMдона
71	YelowSub
72	Marriage
73	MovinOut
74	My Shell
75	NowNever
76	DoLoveMe
77	TcktRide
78	SeeClear
79	Masachus
80	Hard Day
81	USA Pie
82	Norway
83	YesterBd
MODERN POP	
84	Watches
85	SoundMPH
86	Hold Us
87	Unfound
88	NeedSome
89	PrtTmLvr
90	MoonShdw
91	NikitSng
92	Sure of
93	Off Day
94	Tell Her
95	GirlsMne
96	NeedLove
97	Radio
POP CLASSICS	
98	Standing
99	RainLaff
100	Sunshine
101	ForNamdo
102	ThankFor
103	ManPiano
104	CoinLane
105	LovesYou
106	Tmbourin
107	Alone
108	GldField
109	Raindrop
110	SultanSw
111	Life'sWk
112	TopWorld
113	WatchGrl
POP BALLAD	
114	WnderLnd
115	CanIStop
116	EvryTime
117	IvoryAnd
118	TheWorld
119	LovWoman
120	Dolannes
121	Madigan
122	Paradise
123	Whisper
BALLAD	
124	AllOdds
125	AtonalFI
126	Hero
127	Woman
128	RunToYou

MDB No.	MDB Name
129	LoveOfAI
130	CndleWnd
131	Cavatina
132	Cherish
133	ToLoveMe
134	YouKnow
135	Evrythng
136	EyesOfBI
137	Hello
138	BeThere
139	FlyAway
140	LoveYou
141	NeverLet
142	JustOnce
143	IfYouGo
144	SavingAI
145	InTheDrk
146	LovePwr
147	Vision
148	Beautifl
149	AllAlone
150	Opposite
151	BeHonest
152	SayYou
153	SayNthng
154	Stranger
155	OneDay
156	TheBayou
157	ThisSong
158	Distance
159	ThisWay
160	LoveGone
161	Inspirng
162	TrueColr
ROCK & ROLL	
163	ShakenUp
164	Beethovn
165	HurryLov
166	BeCruel
167	Jumping
168	Countdwn
169	SuePeggy
170	Champion
171	Jailhous
172	BlueShoe
173	Rockin24
174	Shouting
175	Rock&Rll
176	HonkyTnk
OLDIES	
177	Daydream
178	Sumertme
179	Diana's
180	Uptown
181	Apache
182	IGottIt
183	Tonight
184	MyPillow
185	NoRain
186	FinalDnc
187	SlpnLion
188	Ghetto
189	LipsLcky
190	PrettyWm
191	TikiGtr
192	TurnThre
193	Sherry






















MDB No.	MDB Name
DANCE & DISCO	
194	Babylon
195	Goodbye
196	Catch22
197	DISCO
198	Survival
199	TheNavy
200	DontHide
201	Celebrat
202	LondonRU
203	10,2 Sun
204	ShakeYou
205	Believe
206	BoySumer
207	I'mSexy
208	StuffHot
SWING & JAZZ	
209	MoonOf
210	Patrol
211	Charles
212	GiveLove
213	HallOfMe
214	Rhythm
215	LOVE
216	LeroyBad
217	Caraban
218	Misbehav
219	Safari
220	Smiling
221	SoWhatIs
222	TimeGone
223	TasteHny
224	Sandman
225	Tunisian
226	TwoFoot
227	MyBaby
R&B	
228	Sally's
229	AsPlayed
230	BabyGrov
231	Highwy66
232	SweetCHI
233	JustU&Me
234	ManLoves
235	OurLove
236	Wish I
237	What
COUNTRY	
238	OnTheRd
239	Breathe
240	InMyMind
241	ContryHw
242	GreenGrs
243	EverNeed
244	Lonesome
245	Lucille
246	HomeRng
247	Tennesse
LATIN	
248	Bananabt
249	DanceMng
250	DntWorry
251	Jamaica
252	FleaSpa
253	I'mPola
254	MamboJm
255	OneNote

MDB No.	MDB Name
256	PasoCani
257	SayNoMor
258	Beguine
259	Tijuana
260	Picture
ENTERTAINMENT	
261	OnTheHil
262	Barnacle
263	Califrag
264	DadClock
265	DanceLd
266	DnceFire
267	CatMemry
268	Cabaret
269	OdeToJoy
270	Mi-Re-Do
271	MyPrince
272	Necessary
273	NoBuiz
274	NoisyOld
275	Sleigh
276	RockBaby
277	Magnifiq
278	JinglBel
279	SilentNt
280	Nabucco
281	Standing
282	SummerPl
283	Christms
284	Favorite
285	Tubbie
286	Turkish
287	RedRdolf
WALTZ & TRAD	
288	Blk&White
289	CanCan
290	Charmain
291	Musicbox
292	Clementn
293	Doodah!
294	Dreamer
295	EnterRag
296	Birthday
297	MaryLamb
298	Donald's
299	MoonWlz
300	MoulinHt
301	Sunshine
302	PieceOf
303	GreenSlv
304	TakeFour
305	TexRose
306	ThePolka
307	Scarboro
308	Edelweis
309	AroundWd
310	Whatever
311	Yankee's
WORLD	
312	Hawaii
313	D'amor
314	ElCondor
315	GoodbyRm
316	ILandOn
317	ItalyBel
318	Cucarumb
319	Puntuali

MDB No.	MDB Name
320	Cielito
321	ItalySun
322	SantaLuc
323	Trumpetr
324	VanMass
PIANIST	
325	RvSwanee
326	BeGood
327	Birdland
328	BlueRose
329	Chaie's
330	Highwy66
331	Leaves
332	Miload
333	Cabaret
334	Wonderfl
335	Imagine
336	LtleStar
337	MapleRag
338	Mi-Re-Do
339	NoBuiz
340	OhBlah
341	Charades
342	Sally's
343	Nabucco
344	SunnyStr
345	MistyFln
346	LdnBridg
347	GrndClick
348	Importnc
349	Snowman
350	Favorite
351	SongForU
352	SugerSpn
353	ThisWay
354	WenSmile
355	ZipperD

Effect Type List

Harmony Types

No.	Harmony Type	Description	
01	Duet	Harmony types 01–05 are pitch-based and add one-, two- or three-note harmonies to the single-note melody played in the right hand. These types sound when chords are played in the auto accompaniment range of the keyboard. These Harmony types will also work when playing songs that contain chord data.	
02	Trio		
03	Block		
04	Country		
05	Octave		
06	Trill 1/4 note		<p>Types 06–26 are rhythm-based effects and add embellishments or delayed repeats in time with the auto accompaniment. These types sound whether the auto accompaniment is on or not; however, the actual speed of the effect depends on the Tempo setting. The individual note values in each type let you synchronize the effect precisely to the rhythm. Triplet settings are also available: 1/6 = quarter-note triplets, 1/12 = eighth-note triplets, 1/24 = sixteenth-note triplets.</p> <ul style="list-style-type: none"> • The Trill effect Types (06–12) create two-note trills (alternating notes) when two notes are held. • The Tremolo effect Types (13–19) repeat all held notes (up to four). • The Echo effect Types (20–26) create delayed repeats of each note played.
07	Trill 1/6 note		
08	Trill 1/8 note		
09	Trill 1/12 note		
10	Trill 1/16 note		
11	Trill 1/24 note		
12	Trill 1/32 note		
13	Tremolo 1/4 note		
14	Tremolo 1/6 note		
15	Tremolo 1/8 note		
16	Tremolo 1/12 note		
17	Tremolo 1/16 note		
18	Tremolo 1/24 note		
19	Tremolo 1/32 note		
20	Echo 1/4 note		
21	Echo 1/6 note		
22	Echo 1/8 note		
23	Echo 1/12 note		
24	Echo 1/16 note		
25	Echo 1/24 note		
26	Echo 1/32 note		

Reverb Types

No.	Reverb Type	Description
01–03	Hall 1–3	Concert hall reverb.
04–05	Room 1–2	Small room reverb.
06–07	Stage 1–2	Reverb for solo instruments.
08–09	Plate 1–2	Simulated steel plate reverb.
10	Off	No effect.

Chorus Types

No.	Chorus Type	Description
01–02	Chorus 1–2	Conventional chorus program with rich, warm chorusing.
03–04	Flanger 1–2	Pronounced three-phase modulation with a slight metallic sound.
05	Off	No effect.